

prior arrangements for a delayed opening. A vessel may make prior arrangements for a delayed opening by contacting the Berkley Bridge Traffic Control room at (757) 494-2490.

[CGD 82-025, 49 FR 43463, Oct. 29, 1984, as amended by CGD 05-88-13, 53 FR 20321, June 3, 1988; CGD 5-89-43, 54 FR 30039, July 18, 1989; CGD5-90-023, 55 FR 23434, June 8, 1990; CGD05-04-209, 70 FR 22254, Apr. 29, 2005; CGD05-05-049, 70 FR 68337, Nov. 10, 2005; USCG-2009-0754, 75 FR 47464, Aug. 6, 2010; USCG-2012-0357, 77 FR 52604, Aug. 30, 2012]

#### § 117.1011 Great Wicomico River.

The draw of the S200 bridge, mile 8.0 at Tipers, shall open on signal; except that, if an opening is desired from 6 p.m. to 6 a.m., the drawtender on duty shall be notified before 6 p.m.

#### § 117.1013 Kinsale Creek.

The draw of the state highway bridge, mile 4.0, at Kinsale need not be opened for the passage of vessels.

#### § 117.1015 Mattaponi River.

The draws of the Lord Delaware (S33) bridge, mile 0.8 at West Point, and the S629 bridge, mile 28.5 at Walkerton, shall open on signal if at least 24 hours notice is given. The drawtender service for either bridge shall be increased to the degree determined to be adequate within 30 days after written notice is received from the District Commander to do so.

#### § 117.1021 North Landing River.

The draw of the S165 bridge, mile 20.2 at Chesapeake, shall open on signal; except that, from 6 a.m. to 7 p.m., the draw need be opened only on the hour and half hour for the passage of pleasure craft. Public vessels of the United States, commercial vessels, and vessels in an emergency endangering life or property shall be passed at any time.

#### § 117.1023 Pamunkey River.

The draw of the Eltham Bridge (SR33/30) mile 1.0, located in West Point, Virginia shall open on signal if at least four hours notice is given at all times.

[USCG-2008-1175, 74 FR 29947, June 24, 2009]

#### § 117.1025 York River.

(a) The Coleman Memorial bridge, mile 7.0, at Yorktown, shall open on signal; except from 5 a.m. to 8 a.m. and 3 p.m. to 7 p.m., Monday through Friday, except Federal holidays, the bridge shall remain closed to navigation.

(b) The bridge shall be opened at any time for vessels in an emergency which presents danger to life or property.

[CGD05-93-054, 59 FR 5954, Feb. 9, 1994, as amended by CGD05-95-023, 60 FR 31247, June 14, 1995]

#### WASHINGTON

#### § 117.1031 Chehalis River.

The draw of the U.S. 101 highway bridge, mile 0.1, at Aberdeen shall open on signal if at least one-hour notice is given at all times by telephone to the Washington State Department of Transportation.

[USCG-2009-0959, 75 FR 16004, Mar. 31, 2010]

#### § 117.1035 Columbia River.

(a) The term *drawtender*, as used in this section means the operator of the drawspan, whether that person may be a train crew member, maintenance person, or an officially designated drawtender.

(b) The draw of the semi-automated Union Pacific railroad bridge (Kalan Bridge), mile 323.4, near Kennewick, Washington, is normally maintained in the fully open position with no drawtender in attendance. A radar beacon (RACON) is located at the center of the drawspan. The RACON operates only when the drawspan is fully open, by responding with the Morse letter "K" to X-band radar signals. When necessary to close the drawspan for the passage of a train or for maintenance, a drawtender shall be dispatched to operate the draw from either of the remote control stations located at the ends of the bridge. Operation of the bridge shall be as follows:

(1) The drawtender shall broadcast a radio message over Channel 16-VHF to all vessels in the vicinity that the Kalan Bridge will be closing in two minutes. If after two minutes no response is received, the drawtender shall broadcast a message over Channel 13-

**§ 117.1037**

**33 CFR Ch. I (7-1-14 Edition)**

VHF that the Kalan Bridge is closing. Both messages shall be broadcast twice.

(2) Prior to activating the closing sequence the drawtender shall visually inspect the waterway for marine traffic approaching the bridge. The closing sequence shall not be activated until after marine traffic has cleared the bridge.

(3) When the closing sequence is activated, the following functions occur automatically: The RACON is deactivated, red strobe lights on the lift towers and on the channel piers start flashing, a downward pointing arrow consisting of amber colored lights is displayed from the center of the drawspan and a recorded message is broadcast over Channel 13-VHF advising that the Kalan Bridge is closed to river traffic. The radio message is repeated every five minutes, the red lights continue to flash and the downward pointing arrow is displayed, until the lift span returns to the up and locked position. At the end of the ten minutes, a horn sounds for 30 seconds, the span begins closing and the centerspan navigation lights turn from green to red. The horn sounds for 30 seconds at 10 minute intervals, until the lift span returns to the up and locked position.

(4) If for any reason during the closing sequence a danger is posed to marine traffic, the closing sequence shall be stopped and the bridge reopened until the threat of danger has passed.

(5) If the bridge is to be temporarily closed for maintenance or for purposes other than the passage of a train, the drawtender shall continually monitor Channels 13 and 16 for calls from approaching vessels, and respond to inquiries from vessels about the closure.

(6) After a train has cleared the bridge, the following functions occur automatically: The drawspan returns to the fully open and locked position, the RACON is reactivated, the arrow display and the red strobe lights are extinguished, the red centerspan navigation lights return to green and a recorded message is broadcast over Channel 13-VHF that the Kalan Bridge is open for marine traffic.

(7) Bridge status information may be obtained by calling the commercial

telephone number posted at the drawspan of the bridge.

(c) The draw of the Burlington Northern Santa Fe railroad bridge at mile 328.0, between Pasco and Kennewick, shall open on signal from 8 a.m. to 4 p.m. At all other times the draw shall open on signal if at least 2 hour's notice is given through the General Yardmaster, Pasco, Washington.

[CGD13 92-02, 57 FR 37712, Aug. 20, 1992]

**§ 117.1037 Cowlitz River.**

(a) The draw of the Burlington Northern Santa Fe railroad bridge, mile 1.5, shall operate as follows:

(1) The draw shall open on signal if at least 24 hours notice is given.

(2) In the event of an emergency declared by the Cowlitz County Department of Emergency Services, the bridge shall be capable of opening upon two hours notice. Notification of emergencies and requests for openings during emergencies are initiated through the Cowlitz County Department of Emergency Services.

(3) The operating machinery of the draw shall be maintained in a serviceable condition and the draw shall be opened and closed at intervals frequent enough to make certain that the machinery is in proper order for satisfactory operation.

(4) During periods of fog or similar periods of reduced visibility, the drawtender, after acknowledging the signal to open, shall toll a bell continuously during the approach and passage of the vessel.

(b) The draw of the Allen Street Bridge, mile 5.5, need not open for the passage of vessels.

[CGD13 91-01, 56 FR 23518, May 22, 1991]

**§ 117.1041 Duwamish Waterway.**

(a) The draws of each bridge across the Duwamish Waterway shall open on signal, except as follows:

(1) From Monday through Friday, except all Federal holidays but Columbus Day, the draws of the First Avenue South Bridges, mile 2.5, need not be opened for the passage of vessels from 6 a.m. to 9 a.m. and from 3 p.m. to 6 p.m., except: The draws shall open at any time for a vessel of 5000 gross tons and over, a vessel towing a vessel of