

§ 250.468 What well records am I required to submit?

(a) You must submit copies of logs or charts of electrical, radioactive, sonic, and other well-logging operations; directional and vertical-well surveys; velocity profiles and surveys; and analysis of cores to BSEE. Each Region will provide specific instructions for submitting well logs and surveys.

(b) For drilling operations in the GOM OCS Region, you must submit form BSEE-0133, Well Activity Report, to the District Manager on a weekly basis.

(c) For drilling operations in the Pacific or Alaska OCS Regions, you must submit form BSEE-0133, Well Activity Report, to the District Manager on a daily basis.

§ 250.469 What other well records could I be required to submit?

The District Manager or Regional Supervisor may require you to submit copies of any or all of the following well records.

(a) Well records as specified in § 250.466;

(b) Paleontological interpretations or reports identifying microscopic fossils by depth and/or washed samples of drill cuttings that you normally maintain for paleontological determinations. The Regional Supervisor may issue a Notice to Lessees that prescribes the manner, timeframe, and format for submitting this information;

(c) Service company reports on cementing, perforating, acidizing, testing, or other similar services; or

(d) Other reports and records of operations.

HYDROGEN SULFIDE

§ 250.490 Hydrogen sulfide.

(a) *What precautions must I take when operating in an H₂S area?* You must:

(1) Take all necessary and feasible precautions and measures to protect personnel from the toxic effects of H₂S and to mitigate damage to property and the environment caused by H₂S. You must follow the requirements of this section when conducting drilling, well-completion/well-workover, and production operations in zones with H₂S present and when conducting oper-

ations in zones where the presence of H₂S is unknown. You do not need to follow these requirements when operating in zones where the absence of H₂S has been confirmed; and

(2) Follow your approved contingency plan.

(b) *Definitions.* Terms used in this section have the following meanings:

Facility means a vessel, a structure, or an artificial island used for drilling, well-completion, well-workover, and/or production operations.

H₂S absent means:

(1) Drilling, logging, coring, testing, or producing operations have confirmed the absence of H₂S in concentrations that could potentially result in atmospheric concentrations of 20 ppm or more of H₂S; or

(2) Drilling in the surrounding areas and correlation of geological and seismic data with equivalent stratigraphic units have confirmed an absence of H₂S throughout the area to be drilled.

H₂S present means that drilling, logging, coring, testing, or producing operations have confirmed the presence of H₂S in concentrations and volumes that could potentially result in atmospheric concentrations of 20 ppm or more of H₂S.

H₂S unknown means the designation of a zone or geologic formation where neither the presence nor absence of H₂S has been confirmed.

Well-control fluid means drilling mud and completion or workover fluid as appropriate to the particular operation being conducted.

(c) *Classifying an area for the presence of H₂S.* You must:

(1) Request and obtain an approved classification for the area from the Regional Supervisor before you begin operations. Classifications are "H₂S absent," "H₂S present," or "H₂S unknown";

(2) Submit your request with your application for permit to drill;

(3) Support your request with available information such as geologic and geophysical data and correlations, well logs, formation tests, cores and analysis of formation fluids; and

(4) Submit a request for reclassification of a zone when additional data indicate a different classification is needed.