

§550.115

30 CFR Ch. V (7-1-12 Edition)

by a lessee or operator of that lease or unit;

(2) The boundaries of contiguous (not cornering) leases that do not have a common lessee or operator;

(3) The boundaries of contiguous (not cornering) leases that have a common lessee or operator but are not owned and operated by that common lessee or operator; or

(4) An unleased block(s).

Sensitive reservoir means a reservoir in which the production rate will affect ultimate recovery.

Significant archaeological resource means those archaeological resources that meet the criteria of significance for eligibility to the National Register of Historic Places as defined in 36 CFR 60.4, or its successor.

Suspension means a granted or directed deferral of the requirement to produce (Suspension of Production (SOP)) or to conduct leaseholding operations (Suspension of Operations (SOO)).

Venting means the release of gas into the atmosphere without igniting it. This includes gas that is released underwater and bubbles to the atmosphere.

Waste of oil, gas, or sulphur means:

(1) The physical waste of oil, gas, or sulphur;

(2) The inefficient, excessive, or improper use, or the unnecessary dissipation of reservoir energy;

(3) The locating, spacing, drilling, equipping, operating, or producing of any oil, gas, or sulphur well(s) in a manner that causes or tends to cause a reduction in the quantity of oil, gas, or sulphur ultimately recoverable under prudent and proper operations or that causes or tends to cause unnecessary or excessive surface loss or destruction of oil or gas; or

(4) The inefficient storage of oil.

Welding means all activities connected with welding, including hot tapping and burning.

Wellbay is the area on a facility within the perimeter of the outermost wellheads.

Well-completion operations mean the work conducted to establish production from a well after the production-casing string has been set, cemented, and pressure-tested.

Well-control fluid means drilling mud, completion fluid, or workover fluid as appropriate to the particular operation being conducted.

Western Gulf of Mexico means all OCS areas of the Gulf of Mexico except those the BOEM Director decides are adjacent to the State of Florida. The Western Gulf of Mexico is not the same as the Western Planning Area, an area established for OCS lease sales.

Workover operations mean the work conducted on wells after the initial well-completion operation for the purpose of maintaining or restoring the productivity of a well.

You means a lessee, the owner or holder of operating rights, a designated operator or agent of the lessee(s), a pipeline right-of-way holder, or a State lessee granted a right-of-use and easement.

PERFORMANCE STANDARDS

§550.115 How do I determine well producibility?

You must follow the procedures in this section to determine well producibility if your well is not in the GOM. If your well is in the GOM you must follow the procedures in either this section or in §550.116 of this subpart.

(a) You must write to the Regional Supervisor asking for permission to determine producibility.

(b) You must either:

(1) Allow the Regional Supervisor to witness each test that you conduct under this section; or

(2) Receive the Regional Supervisor prior approval so that you can submit either test data with your affidavit or third party test data.

(c) If the well is an oil well, you must conduct a production test that lasts at least 2 hours after flow stabilizes.

(d) If the well is a gas well, you must conduct a deliverability test that lasts at least 2 hours after flow stabilizes, or a four-point back pressure test.

§550.116 How do I determine producibility if my well is in the Gulf of Mexico?

If your well is in the GOM, you must follow either the procedures in §550.115 of this subpart or the procedures in this section to determine producibility.