

§ 761.253

40 CFR Ch. I (7–1–13 Edition)

smaller sections to be a separate abandonment and sample each one, at a minimum, at all ends.

(3) Use the following procedure to locate representative sample collection sites in pipeline sections at points other than the suction and pressure side of compressor stations, or the ends of the pipeline section to be abandoned.

(i) First, assign a unique identifying sequential number to each kilometer or fraction of a kilometer length of pipe within the entire pipeline section.

(ii) Use a random number table or a random number generator to select each representative sample collection site from a complete list of the sequential identification numbers.

(iii) Samples may be collected by removing any covering soil, cutting the pipe to gain access to the sampling location, and collecting the surface sample with the pipe in place, rather than completely removing the pipeline sections to collect the surface sample.

[63 FR 35462, June 29, 1998, as amended at 64 FR 33762, June 24, 1999]

§ 761.253 Chemical analysis.

(a) Extract PCBs from the standard wipe sample collection medium and clean-up the extracted PCBs in accordance with either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

(b) Report all PCB sample concentrations in $\mu\text{g}/100\text{ cm}^2$ (16 square inches) of surface sampled. If sampling an area smaller than 100 cm^2 , report converted sample concentrations in accordance with § 761.243(b).

§ 761.257 Determining the regulatory status of sampled pipe.

(a) For purposes of removal for disposal of a pipe segment that has been sampled, the sample results for that segment determines its PCB surface concentration. Determine the PCB surface concentration of a segment which was not sampled as follows:

(1) If the unsampled pipe segment is between two pipe segments which have been sampled, assume that the

unsampled segment has the same PCB surface concentration as the nearest sampled pipe segment.

(2) If an unsampled pipe segment is equidistant between two pipe segments which have been sampled, assume the PCB surface concentration of the unsampled segment to be the arithmetic mean of the PCB surface concentrations measured in the two equidistant, sampled, pipe segments.

(b) For purposes of abandonment of a pipeline section, assume that the PCB surface concentration for an entire pipeline section is the arithmetic mean of the PCB surface concentrations measured at the ends of the pipeline section. If additional representative samples were taken in a pipeline section, assume that the PCB surface concentration for the entire pipeline section is the arithmetic mean of the concentrations measured in all representative samples taken.

(c) For purposes of removal for disposal under § 761.60(b)(5)(ii)(A)(I) or abandonment under § 761.60(b)(5)(i)(B), if the surface PCB concentration of a pipe segment, determined by direct measurement or in accordance with paragraph (a) of this section, or of a pipeline section as determined in accordance with paragraph (b) of this section, is $>10\text{ }\mu\text{g}/100\text{ cm}^2$, but $<100\text{ }\mu\text{g}/100\text{ cm}^2$, then that segment or section is PCB-Contaminated.

Subpart N—Cleanup Site Characterization Sampling for PCB Remediation Waste in Accordance with § 761.61(a)(2)

SOURCE: 63 FR 35464, June 29, 1998, unless otherwise noted.

§ 761.260 Applicability.

This subpart provides a method for collecting new data for characterizing a PCB remediation waste cleanup site or for assessing the sufficiency of existing site characterization data, as required by § 761.61(a)(2).

§ 761.265 Sampling bulk PCB remediation waste and porous surfaces.

(a) Use a grid interval of 3 meters and the procedures in §§ 761.283 and 761.286 to sample bulk PCB remediation waste