

§§ 250.607–250.608 [Reserved]

§ 250.609 Well-workover structures on fixed platforms.

Derricks, masts, substructures, and related equipment shall be selected, designed, installed, used, and maintained so as to be adequate for the potential loads and conditions of loading that may be encountered during the operations proposed. Prior to moving a well-workover rig or well-servicing equipment onto a platform, the lessee shall determine the structural capability of the platform to safely support the equipment and proposed operations, taking into consideration the corrosion protection, age of the platform, and previous stresses to the platform.

§ 250.610 Diesel engine air intakes.

No later than May 31, 1989, diesel engine air intakes shall be equipped with a device to shut down the diesel engine in the event of runaway. Diesel engines which are continuously attended shall be equipped with either remote operated manual or automatic shutdown devices. Diesel engines which are not continuously attended shall be equipped with automatic shutdown devices.

§ 250.611 Traveling-block safety device.

After May 31, 1989, all units being used for well-workover operations which have both a traveling block and a crown block shall be equipped with a safety device which is designed to prevent the traveling block from striking the crown block. The device shall be checked for proper operation weekly and after each drill-line slipping operation. The results of the operational check shall be entered in the operations log.

§ 250.612 Field well-workover rules.

When geological and engineering information available in a field enables the District Manager to determine specific operating requirements, field well-workover rules may be established on the District Manager's initiative or in response to a request from a lessee. Such rules may modify the specific requirements of this subpart. After field

well-workover rules have been established, well-workover operations in the field shall be conducted in accordance with such rules and other requirements of this subpart. Field well-workover rules may be amended or canceled for cause at any time upon the initiative of the District Manager or upon the request of a lessee.

§ 250.613 Approval and reporting for well-workover operations.

(a) No well-workover operation except routine ones, as defined in § 250.601 of this part, shall begin until the lessee receives written approval from the District Manager. Approval for these operations must be requested on Form BSEE-0124, Application for Permit to Modify.

(b) You must submit the following with Form BSEE-0124:

(1) A brief description of the well-workover procedures to be followed, a statement of the expected surface pressure, and type and weight of workover fluids;

(2) When changes in existing subsurface equipment are proposed, a schematic drawing of the well showing the zone proposed for workover and the workover equipment to be used;

(3) All information required in § 250.615.

(4) Where the well-workover is in a zone known to contain H₂S or a zone where the presence of H₂S is unknown, information pursuant to § 250.490 of this part; and

(5) Payment of the service fee listed in § 250.125.

(c) The following additional information shall be submitted with Form BSEE-0124 if completing to a new zone is proposed:

(1) Reason for abandonment of present producing zone including supportive well test data, and

(2) A statement of anticipated or known pressure data for the new zone.

(d) Within 30 days after completing the well-workover operation, except routine operations, Form BSEE-0124, Application for Permit to Modify, shall be submitted to the District Manager, showing the work as performed. In the case of a well-workover operation resulting in the initial recompletion of a well into a new zone, a Form BSEE-

§ 250.614

0125, End of Operations Report, shall be submitted to the District Manager and shall include a new schematic of the tubing subsurface equipment if any subsurface equipment has been changed.

[76 FR 64462, Oct. 18, 2011, as amended at 77 FR 50895, Aug. 22, 2012]

§ 250.614 Well-control fluids, equipment, and operations.

The following requirements apply during all well-workover operations with the tree removed:

(a) Well-control fluids, equipment, and operations shall be designed, utilized, maintained, and/or tested as necessary to control the well in foreseeable conditions and circumstances, including subfreezing conditions. The well shall be continuously monitored during well-workover operations and shall not be left unattended at anytime unless the well is shut in and secured.

(b) When coming out of the hole with drill pipe or a workover string, the annulus shall be filled with well-control fluid before the change in such fluid level decreases the hydrostatic pressure 75 pounds per square inch (psi) or every five stands of drill pipe or workover string, whichever gives a lower decrease in hydrostatic pressure. The number of stands of drill pipe or workover string and drill collars that may be pulled prior to filling the hole and the equivalent well-control fluid volume shall be calculated and posted near the operator's station. A mechanical, volumetric, or electronic device for measuring the amount of well-control fluid required to fill the hold shall be utilized.

(c) The following well-control-fluid equipment shall be installed, maintained, and utilized:

(1) A fill-up line above the uppermost BOP;

(2) A well-control, fluid-volume measuring device for determining fluid volumes when filling the hole on trips; and

(3) A recording mud-pit-level indicator to determine mud-pit-volume gains and losses. This indicator shall include both a visual and an audible warning device.

(d) Before you displace kill-weight fluid from the wellbore and/or riser to

30 CFR Ch. II (7-1-14 Edition)

an underbalanced state, you must obtain approval from the BSEE District Manager. To obtain approval, you must submit with your APM your reasons for displacing the kill-weight fluid and provide detailed step-by-step written procedures describing how you will safely displace these fluids. The step-by-step displacement procedures must address the following:

(1) Number and type of independent barriers, as described in §250.420(b)(3), that are in place for each flow path that requires such barriers,

(2) Tests you will conduct to ensure integrity of independent barriers,

(3) BOP procedures you will use while displacing kill weight fluids, and

(4) Procedures you will use to monitor the volumes and rates of fluids entering and leaving the wellbore.

[76 FR 64462, Oct. 18, 2011, as amended at 77 FR 50895, Aug. 22, 2012]

§ 250.615 What BOP information must I submit?

For well-workover operations, your APM must include the following BOP descriptions:

(a) A description of the BOP system and system components, including pressure ratings of BOP equipment and proposed BOP test pressures;

(b) A schematic drawing of the BOP system that shows the inside diameter of the BOP stack, number and type of preventers, all control systems and pods, location of choke and kill lines, and associated valves;

(c) Independent third-party verification and supporting documentation that show the blind-shear rams installed in the BOP stack are capable of shearing any drill pipe (including workstring and tubing) in the hole under maximum anticipated surface pressure. The documentation must include actual shearing and subsequent pressure integrity test results for the most rigid pipe to be used and calculations of shearing capacity of all pipe to be used in the well, including correction for under maximum anticipated surface pressure;

(d) When you use a subsea BOP stack, independent third-party verification that shows: