§ 250.440

- (b) Require your onsite representative to sign and date the pressure test chart:
- (c) Identify the control station used during the test or actuation;
- (d) Identify problems or irregularities observed during the testing or actuations and record actions taken to remedy the problems or irregularities; and
- (e) Retain all pressure charts and reports pertaining to the diverter tests and actuations at the facility for the duration of drilling the well.

[68 FR 8423, Feb. 20, 2003]

BLOWOUT PREVENTER (BOP) SYSTEM REQUIREMENTS

§ 250.440 What are the general requirements for BOP systems and system components?

You must design, install, maintain, test, and use the BOP system and system components to ensure well control. The working-pressure rating of each BOP component must exceed maximum anticipated surface pressures. The BOP system includes the BOP stack and associated BOP systems and equipment.

[68 FR 8423, Feb. 20, 2003]

§ 250.441 What are the requirements for a surface BOP stack?

- (a) When you drill with a surface BOP stack, you must install the BOP system before drilling below surface casing. The surface BOP stack must include at least four remote-controlled, hydraulically operated BOPs, consisting of an annular BOP, two BOPs equipped with pipe rams, and one BOP equipped with blind or blind-shear rams
- (b) Your surface BOP stack must include at least four remote-controlled, hydraulically operated BOPs consisting of an annular BOP, two BOPs equipped with pipe rams, and one BOP equipped with blind-shear rams. The blind-shear rams must be capable of shearing the drill pipe that is in the hole.
- (c) You must install an accumulator system that provides 1.5 times the volume of fluid capacity necessary to close and hold closed all BOP components. The system must perform with a minimum pressure of 200 psi above the precharge pressure without assistance

from a charging system. If you supply the accumulator regulators by rig air and do not have a secondary source of pneumatic supply, you must equip the regulators with manual overrides or other devices to ensure capability of hydraulic operations if rig air is lost.

(d) In addition to the stack and accumulator system, you must install the associated BOP systems and equipment required by the regulations in this subpart.

[68 FR 8423, Feb. 20, 2003, as amended at 74 FR 46908, Sept. 14, 2009]

§ 250.442 What are the requirements for a subsea BOP stack?

- (a) When you drill with a subsea BOP stack, you must install the BOP system before drilling below surface casing. The District Manager may require you to install a subsea BOP system before drilling below the conductor casing if proposed casing setting depths or local geology indicate the need.
- (b) Your subsea BOP stack must include at least four remote-controlled, hydraulically operated BOPs consisting of an annular BOP, two BOPs equipped with pipe rams, and one BOP equipped with blind-shear rams.
- (c) You must install an accumulator closing system to provide fast closure of the BOP components and to operate all critical functions in case of a loss of the power fluid connection to the surface. The accumulator system must meet or exceed the provisions of Section 13.3, Accumulator Volumetric Capacity, in API RP 53, Recommended Practices for Blowout Prevention Equipment Systems for Drilling Wells (incorporated by reference as specified in §250.198). The District Manager may approve a suitable alternative method.
- (d) The BOP system must include an operable dual-pod control system to ensure proper and independent operation of the BOP system.
- (e) Before removing the marine riser, you must displace the riser with seawater. You must maintain sufficient hydrostatic pressure or take other suitable precautions to compensate for the reduction in pressure and to maintain a safe and controlled well condition

[68 FR 8423, Feb. 20, 2003]