

## Coast Guard, DHS

## § 112.55-1

(j) An independent fuel supply must be provided for the prime mover.

(k) Each emergency generator that is arranged to be automatically started must be equipped with a starting device with an energy-storage capability of at least six consecutive starts. A second, separate source of starting energy may provide three of the required six starts. If a second source is provided, the system need only provide three consecutive starts.

[CGD 74-125A, 47 FR 15267, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28287, June 4, 1996; USCG-2004-18884, 69 FR 58348, Sept. 30, 2004]

### § 112.50-3 Hydraulic starting.

A hydraulic starting system must meet the following:

(a) The hydraulic starting system must be a self-contained system that provides the cranking torque and engine starting RPM recommended by the engine manufacturer. The hydraulic starting system must be capable of six consecutive starts, unless a second, separate source of starting energy capable of three consecutive starts is provided. A second, separate source of starting energy may provide three of the required six starts. If a second source is provided, the hydraulic system need only provide three consecutive starts.

(b) The stored hydraulic pressure must be automatically maintained within the predetermined pressure limits.

(c) The means of automatically maintaining the hydraulic system within the predetermined pressure limits must be electrically energized from the final emergency bus.

(d) There must be a means to manually recharge the hydraulic system.

(e) Charging of the hydraulic starting system must not cause insufficient hydraulic pressure for engine starting.

[CGD 74-125A, 47 FR 15267, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28287, June 4, 1996]

### § 112.50-5 Electric starting.

An electric starting system must have a starting battery with sufficient capacity for at least six consecutive starts. A second, separate source of starting energy may provide three of

the required six starts. If a second source is provided, the electrical starting system need only provide three consecutive starts.

[CGD 94-108, 61 FR 28288, June 4, 1996]

### § 112.50-7 Compressed air starting.

A compressed air starting system must meet the following:

(a) The starting, charging, and energy storing devices must be in the emergency generator room, except for the main or auxiliary air compressors addressed in paragraph (c)(3)(i) of this section.

(b) The compressed air starting system must provide the cranking torque and engine starting RPM recommended by the engine manufacturer.

(c) The compressed air starting system must have an air receiver that meets the following:

(1) Has a capacity for at least six consecutive starts. A second, separate source of starting energy may provide three of the required consecutive starts. If a second source is provided, the compressed air starting system need only provide three consecutive starts.

(2) Supplies no other system.

(3) Is supplied from one of the following:

(i) The main or auxiliary compressed air receivers with a nonreturn valve in the emergency generator room and a handcranked, diesel-powered air compressor for recharging the air receiver.

(ii) An electrically driven air compressor that is automatically operated and is powered from the emergency power source. If this compressor supplies other auxiliaries, there must be a non-return valve at the inlet of the starting air receiver and there must be a handcranked, diesel-powered air compressor for recharging the air receiver.

[CGD 74-125A, 47 FR 15267, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28288, June 4, 1996]

## Subpart 112.55—Storage Battery Installation

### § 112.55-1 General.

Each storage battery installation must meet Subpart 111.15 of this chapter.