

**§97.15-5**

**46 CFR Ch. I (10-1-11 Edition)**

**§97.15-5 Drafts and load line markings.**

(a) The master of every vessel on an ocean, coastwise, or Great Lakes voyage shall enter the drafts of the vessel, forward and aft, in the official logbook when leaving port.

(b) On vessels subject to the requirements of subchapter E (Load Lines) of this chapter at the time of departure from port on an ocean, coastwise, or Great Lakes voyage, the master shall insert in the official logbook a statement of the position of the load line mark, port and starboard, in relation to the surface of the water in which the vessel is then floating.

(1) When an allowance for draft is made for density of the water in which the vessel is floating, this density is to be noted in the official logbook.

**§97.15-7 Verification of vessel compliance with applicable stability requirements.**

(a) Except as provided in paragraph (d) of this section, after loading and prior to departure and at all other times necessary to assure the safety of the vessel, the master or person in charge shall determine that the vessel complies with all applicable stability requirements in the vessel's trim and stability book, stability letter, Certificate of Inspection, and Load Line Certificate, as the case may be. The vessel may not depart until it is in compliance with these requirements.

(b) When determining compliance with applicable stability requirements the vessel's draft, trim, and stability must be determined as necessary.

(c) If a log book is required by §97.35, then the master or person in charge must enter an attestation statement verifying that the vessel complies with the applicable stability requirements at the times specified in paragraph (a) and any stability calculations made in support of the determination must be retained on board the vessel for the duration of the voyage.

(d) Stability verification is not required for tank barges whose Certificate of Inspection carries draft restrictions for purposes other than stability.

[CGD 89-037, 57 FR 41822, Sept. 11, 1992]

**§97.15-10 Sanitation.**

(a) It shall be the duty of the master and chief engineer to see that the vessel, and, in particular, the quarters are in a clean and sanitary condition. The chief engineer shall be responsible only for the sanitary condition of the engineering department.

**§97.15-15 Examination of boilers and machinery.**

It shall be the duty of the chief engineer when assuming charge of the boilers and machinery of a vessel to examine them thoroughly. If any parts thereof are in bad condition, the fact shall immediately be reported to the master, owner or agent, and the Officer in Charge, Marine Inspection.

[CGD 95-028, 62 FR 51207, Sept. 30, 1997]

**§97.15-17 Loading doors.**

(a) The master of a vessel fitted with loading doors shall assure that all loading doors are closed watertight and secured during the entire voyage except that—

(1) If a door cannot be opened or closed while the vessel is at a dock, it may be open while the vessel approaches and draws away from the dock, but only as far as necessary to enable the door to be immediately operated;

(2) If needed to operate the vessel, or embark and disembark passengers when the vessel is at anchor in protected waters, loading doors may be open provided that the master determines that the safety of the vessel is not impaired.

(b) For the purposes of this section, "loading doors" include all weather-tight ramps, bow visors, and openings used to load personnel, equipment, cargo, and stores, in the collision bulkhead, the side shell, and the boundaries of enclosed superstructures that are continuous with the shell of the vessel.

(c) The master shall enter into the log book the time and door location of every closing of the loading doors.

(d) The master shall enter into the log book any opening of the doors in accordance with paragraph (a)(2) of this section setting forth the time of

the opening of the doors and the circumstances warranting this action.

[CGD 89-037, 57 FR 41823, Sept. 11, 1992]

**§ 97.15-20 Hatches and other openings.**

(a)(1) With the exception stated in paragraph (a)(2) of this section, it shall be the responsibility of the master to assure himself that all exposed cargo hatches and other openings in the hull of his vessel are closed, made properly watertight by the use of tarpaulins, gaskets or similar devices, and in all respects properly secured for sea before leaving protected waters.

(2) A vessel engaged in a voyage exclusively on Great Lakes waters and having 6 feet or more of freeboard, measured vertically from the water's edge at the lowest point of sheer to the top of deck at the ship's side, may, at the master's discretion, omit tarpaulins on the ship's hatches from 16 May through 15 September (both dates inclusive). This exemption does not relieve the master of any responsibility for the securing and protection of his hatches during the interval of exemption and, in case of indications of bad weather or other threatening conditions, he shall not leave protected waters until the exposed cargo hatches and other openings in the hull of his vessel are properly covered, secured and protected.

(b) The openings to which this section applies are as follows:

(1) Exposed cargo hatches.

(2) Gangway, cargo and coaling ports fitted below the freeboard deck.

(3) Port lights that are not accessible during navigation including the dead lights for such port lights.

(c) Vessels which, by their design, do not require cargo hatch closing devices and to which § 45.01-20 of subchapter E (Load Lines) of this chapter applies need not comply with the requirements of this section as to exposed cargo hatches.

(d) The master at his discretion may permit hatches or other openings to remain uncovered or open, or to be uncovered or opened for reasonable purposes such as ship's maintenance while the vessel is being navigated: *Provided*, That in his opinion existing conditions warrant such action.

(e) In the event the master employs the discretionary provisions of this section after leaving port he shall cause appropriate entries to be made in the official log or equivalent thereof setting forth the time of uncovering, opening, closing or covering of the hatches or other openings to which this section applies and the circumstances warranting the action taken.

(f) The discretionary provisions of this section shall not relieve the master of his responsibility for the safety of his vessel, her crew or cargo.

**§ 97.15-30 Emergency lighting and power systems.**

(a) Where fitted, it shall be the duty of the master to see that the emergency lighting and power systems are operated and inspected at least once in each week that the vessel is navigated to be assured that the system is in proper operating condition.

(b) Internal combustion engine driven emergency generators shall be operated under load for at least 2 hours, at least once in each month that the vessel is navigated.

(c) Storage batteries for emergency lighting and power systems shall be tested at least once each 6-month period that the vessel is navigated to demonstrate the ability of the storage battery to supply the emergency loads for the period of time specified in Table 112.05-5(a) of this chapter.

(d) The date of the tests and the condition and performance of the apparatus shall be noted in the official log book.

[CGFR 65-50, 30 FR 17014, Dec. 30, 1965, as amended by CGFR 70-143, 35 FR 19906, Dec. 30, 1970; 36 FR 5606, Mar. 25, 1971]

**§ 97.15-35 Emergency training, musters, and drills.**

Onboard training, musters, and drills must be in accordance with subchapter W (Lifesaving Appliances and Arrangements) of this chapter.

[CGD 84-069, 61 FR 25289, May 20, 1996]

**§ 97.15-55 Requirements for fuel oil.**

(a) It shall be the duty of the chief engineer to cause an entry in the log to be made of each supply of fuel oil received on board, stating the quantity