Environmental Protection Agency

(2)(i)(A) The monofill has at least one liner for which there is no evidence that such liner is leaking. For the purposes of this paragraph, the term 'liner'' means a liner designed, constructed, installed, and operated to prevent hazardous waste from passing into the liner at any time during the active life of the facility, or a liner designed, constructed, installed, and operated to prevent hazardous waste from migrating beyond the liner to adjacent subsurface soil, ground water, or surface water at any time during the active life of the facility. In the case of any surface impoundment which has been exempted from the requirements of paragraph (c) of this section on the basis of a liner designed, constructed, installed, and operated to prevent hazardous waste from passing beyond the liner, at the closure of such impoundment, the owner or operator must remove or decontaminate all waste residues, all contaminated liner material, and contaminated soil to the extent practicable. If all contaminated soil is not removed or decontaminated, the owner or operator of such impoundment will comply with appropriate post-closure requirements, including but not limited to ground-water monitoring and corrective action;

- (B) The monofill is located more than one-quarter mile from an "underground source of drinking water" (as that term is defined in 40 CFR 270.2); and
- (C) The monofill is in compliance with generally applicable ground-water monitoring requirements for facilities with permits under RCRA section 3005(c); or
- (ii) The owner or operator demonstrates that the monofill is located, designed and operated so as to assure that there will be no migration of any hazardous constituent into ground water or surface water at any future time.
- (f) The owner or operator of any replacement surface impoundment unit is exempt from paragraph (c) of this section if:
- (1) The existing unit was constructed in compliance with the design standards of sections $3004\ (o)(1)(A)(i)$ and (o)(5) of the Resource Conservation and Recovery Act; and

- (2) There is no reason to believe that the liner is not functioning as designed.
- (g) A surface impoundment must be designed, constructed, maintained, and operated to prevent overtopping resulting from normal or abnormal operations; overfilling; wind and wave action; rainfall; run-on; malfunctions of level controllers, alarms, and other equipment; and human error.
- (h) A surface impoundment must have dikes that are designed, constructed, and maintained with sufficient structural integrity to prevent massive failure of the dikes. In ensuring structural integrity, it must not be presumed that the liner system will function without leakage during the active life of the unit.
- (i) The Regional Administrator will specify in the permit all design and operating practices that are necessary to ensure that the requirements of this section are satisfied.

[47 FR 32357, July 26, 1982, as amended at 50 FR 4514, Jan. 31, 1985; 50 FR 28747, July 15, 1985; 57 FR 3487, Jan. 29, 1992; 71 FR 40273, July 14, 2006]

§ 264.222 Action leakage rate.

- (a) The Regional Administrator shall approve an action leakage rate for surface impoundment units subject to §264.221 (c) or (d). The action leakage rate is the maximum design flow rate that the leak detection system (LDS) can remove without the fluid head on the bottom liner exceeding 1 foot. The action leakage rate must include an adequate safety margin to allow for uncertainties in the design (e.g., slope, hydraulic conductivity, thickness of drainage material), construction, operation, and location of the LDS, waste and leachate characteristics, likelihood and amounts of other sources of liquids in the LDS, and proposed response actions (e.g., the action leakage rate must consider decreases in the flow capacity of the system over time resulting from siltation and clogging, rib layover and creep of synthetic components of the system, overburden pressures, etc.).
- (b) To determine if the action leakage rate has been exceeded, the owner or operator must convert the weekly or monthly flow rate from the monitoring

§ 264.223

data obtained under §264.226(d) to an average daily flow rate (gallons per acre per day) for each sump. Unless the Regional Administrator approves a different calculation, the average daily flow rate for each sump must be calculated weekly during the active life and closure period, and if the unit is closed in accordance with §264.228(b), monthly during the post-closure care period when monthly monitoring is required under §264.226(d).

[57 FR 3487, Jan. 29, 1992]

§ 264.223 Response actions.

- (a) The owner or operator of surface impoundment units subject to §264.221 (c) or (d) must have an approved response action plan before receipt of waste. The response action plan must set forth the actions to be taken if the action leakage rate has been exceeded. At a minimum, the response action plan must describe the actions specified in paragraph (b) of this section.
- (b) If the flow rate into the leak detection system exceeds the action leakage rate for any sump, the owner or operator must:
- (1) Notify the Regional Administrator in writing of the exceedance within 7 days of the determination;
- (2) Submit a preliminary written assessment to the Regional Administrator within 14 days of the determination, as to the amount of liquids, likely sources of liquids, possible location, size, and cause of any leaks, and short-term actions taken and planned;
- (3) Determine to the extent practicable the location, size, and cause of any leak:
- (4) Determine whether waste receipt should cease or be curtailed, whether any waste should be removed from the unit for inspection, repairs, or controls, and whether or not the unit should be closed;
- (5) Determine any other short-term and longer-term actions to be taken to mitigate or stop any leaks; and
- (6) Within 30 days after the notification that the action leakage rate has been exceeded, submit to the Regional Administrator the results of the analyses specified in paragraphs (b) (3), (4), and (5) of this section, the results of actions taken, and actions planned. Monthly thereafter, as long as the flow

rate in the leak detection system exceeds the action leakage rate, the owner or operator must submit to the Regional Administrator a report summarizing the results of any remedial actions taken and actions planned.

- (c) To make the leak and/or remediation determinations in paragraphs (b) (3), (4), and (5) of this section, the owner or operator must:
- (1)(i) Assess the source of liquids and amounts of liquids by source,
- (ii) Conduct a fingerprint, hazardous constituent, or other analyses of the liquids in the leak detection system to identify the source of liquids and possible location of any leaks, and the hazard and mobility of the liquid; and
- (iii) Assess the seriousness of any leaks in terms of potential for escaping into the environment; or
- (2) Document why such assessments are not needed.

[57 FR 3488, Jan. 29, 1992, as amended at 71 FR 40273, July 14, 2006]

§§ 264.224-264.225 [Reserved]

§ 264.226 Monitoring and inspection.

- (a) During construction and installation, liners (except in the case of existing portions of surface impoundments exempt from §264.221(a)) and cover systems (e.g., membranes, sheets, or coatings) must be inspected for uniformity, damage, and imperfections (e.g., holes, cracks, thin spots, or foreign materials). Immediately after construction or installation:
- (1) Synthetic liners and covers must be inspected to ensure tight seams and joints and the absence of tears, punctures, or blisters; and
- (2) Soil-based and admixed liners and covers must be inspected for imperfections including lenses, cracks, channels, root holes, or other structural non-uniformities that may cause an increase in the permeability of the liner or cover.
- (b) While a surface impoundment is in operation, it must be inspected weekly and after storms to detect evidence of any of the following:
- (1) Deterioration, malfunctions, or improper operation of overtopping control systems;
- (2) Sudden drops in the level of the impoundment's contents; and