

§§ 1918.70–1918.80

cuts. The lower guard shall cover the saw to the depth of the teeth, except for the minimum arc required to allow proper retraction and contact with the work. When the tool is withdrawn from the work, the lower guard shall automatically and instantly return to the covering position.

[62 FR 40202, July 25, 1997, as amended at 65 FR 40946, June 30, 2000]

§§ 1918.70–1918.80 [Reserved]

Subpart H—Handling Cargo

§ 1918.81 Slinging.

(a) Drafts shall be safely slung before being hoisted. Loose dunnage or debris hanging or protruding from loads shall be removed.

(b) Cargo handling bridles, such as pallet bridles, which are to remain attached to the hoisting gear while hoisting successive drafts, shall be attached by shackles, or other positive means shall be taken to prevent them from being accidentally disengaged from the cargo hook.

(c) Drafts of lumber, pipe, dunnage and other pieces, the top layer of which is not bound by the sling, shall be slung in a way that prevents sliders. Double slings shall be used on unstrapped dunnage, unless, due to the size of hatch or deep tank openings, using them is impracticable.

(d) Case hooks shall be used only with cases designed to be hoisted by these hooks.

(e) Bales of cotton, wool, cork, wood pulp, gunny bags or similar articles shall not be hoisted by straps unless the straps are strong enough to support the weight of the bale. At least two hooks, each in a separate strap, shall be used.

(f) Unitized loads bound by bands or straps may be hoisted by the banding or strapping only if the banding or strapping is suitable for hoisting and is strong enough to support the weight of the load.

(g) Additional means to maintain the unitized loads during hoisting shall be employed to ensure safe lifting of such loads having damaged banding or strapping.

(h) Loads requiring continuous manual guidance during handling shall be

29 CFR Ch. XVII (7–1–14 Edition)

guided by guide ropes (tag lines) that are long enough to control the load.

(i) No draft shall be hoisted unless the winch or crane operator(s) can clearly see the draft itself or see the signals of a signalman who is observing the draft's movement.

(j) Intermodal containers shall be handled in accordance with § 1918.85.

(k) The employer shall require that employees stay clear of the area beneath overhead drafts or descending lifting gear.

(l) The employer shall not permit employees to ride the hook or the load, except as provided for in § 1918.85(g).

§ 1918.82 Building drafts.

(a) Drafts shall be built or means shall be taken to prevent cargo from falling from them.

(b) Buckets and tubs used in handling bulk or frozen cargo shall not be loaded above their rims.

§ 1918.83 Stowed cargo; tiering and breaking down.

(a) When necessary to protect personnel working in a hold, the employer shall secure or block stowed cargo that is likely to shift or roll.

(b) In breaking down stowed cargo, precautions shall be taken to prevent remaining cargo from falling.

(c) Employees trimming bulk cargo shall be checked in and out by the job boss. Before securing any reefer compartment, a check shall be made to ensure that no employee remains inside. Frequent checks shall be made to ensure the safety of any employee working alone in a tank or cargo compartment.

§ 1918.84 Bulling cargo.

(a) Bulling cargo shall be done with the bull line led directly from the heel block. However, bulling may be done from the head of the boom when the nature of the cargo and the surface over which it is dragged are such that the load cannot be stalled, or when the winch actually does not have sufficient strength, with the purchase used, to overload the boom.

(b) Snatch blocks shall be used to provide a fair lead for the bull line to avoid unnecessary dragging of the bull

line against coamings and obstructions.

(c) Snatch blocks shall not be used with the point of the hook resting on the flange of a beam, but shall be hung from padeyes, straps, or beam clamps. Snatch blocks or straps shall not be made fast to batten cleats or other insecure fittings.

(d) Beam frame clamps shall be so secured as to prevent their slipping, falling, or being pulled from their stationary attachment.

(e) Falls led from cargo booms of vessels shall not be used to move scows, lighters or railcars.

§ 1918.85 Containerized cargo operations.

(a) *Container markings.* Every intermodal container shall be legibly and permanently marked with:

(1) The weight of the container when empty, in pounds;

(2) The maximum cargo weight the container is designed to carry, in pounds; and

(3) The sum of the weight of the container and the maximum cargo weight, in pounds.

(b) *Container weight.* No container shall be hoisted by any lifting appliance unless the following conditions have been met:

(1) The employer shall determine from the carrier whether a container to be hoisted is loaded or empty. Before loading or discharging, empty containers shall be identified in a manner that will inform every supervisor and job boss on the site and in charge of loading or discharging, or every crane or other hoisting equipment operator and signalman, that such container is empty. Methods of identification may include cargo plans, manifests, or markings on the container.

(2) For a loaded container:

(i) The actual gross weight shall be plainly marked and visible to the crane or other hoisting equipment operator or signalman, or to every supervisor or job boss on site and in charge of the operation; or

(ii) The cargo stowage plan or equivalent permanently recorded display serving the same purpose, containing the actual gross weight and the serial number or other positive identification

of that specific container, shall be provided to the crane or other hoisting equipment operator and signalman, and to every supervisor and job boss on site and in charge of the operation.

(3) Every outbound container received at a marine terminal ready to load aboard a vessel without further consolidation or loading shall be weighed to obtain the actual gross weight, either at the terminal or elsewhere, before being hoisted.

(4)(i) When container weighing scales are found at a marine terminal, any outbound container with a load consolidated at that terminal shall be weighed to obtain the actual weight before being hoisted.

(ii) If the terminal has no scales, the actual gross weight may be calculated from the container's contents and the container's empty weight. The weights used in the calculation shall be posted conspicuously on the container, with the name of the person making the calculation, and the date.

(5) Open top vehicle-carrying containers, and those built specifically and used solely for the carriage of compressed gases, are excepted from paragraphs (b)(3) and (b)(4) of this section.

(6) Closed dry van containers carrying vehicles are exempted from paragraph (b)(4) of this section if:

(i) The container carries only completely assembled vehicles and no other cargo;

(ii) The container is marked on the outside so that an employee can readily discern that the container is carrying vehicles; and

(iii) The vehicles were loaded into the container at the marine terminal.

(7) The weight of loaded inbound containers from foreign ports shall be determined by weighing, by the method of calculation described in paragraph (b)(4)(ii) of this section or by shipping documents.

(8) Any scale used within the United States to weigh containers for the requirements of this section shall meet the accuracy standards of the state or local public authority in which the scale is found.

(c) *Overloaded containers.* No container shall be hoisted if its actual gross weight exceeds the weight marked as required in paragraph (a)(3)