Environmental Protection Agency

target compounds are suspended. The owner or operator shall prepare a sampling plan. Wastewater samples shall be collected using sampling procedures which minimize loss of organic compounds during sample collection and analysis and maintain sample integrity. The sample plan shall include procedures for determining recovery efficiency of the relevant compounds regulated in the applicable subpart. An example of an acceptable sampling plan would be one that incorporates similar sampling and sample handling requirements to those of Method 25D of 40 CFR part 60, appendix A.

2.1. Sampling and Analysis

2.1.1. For each waste matrix, collect twice the number of samples required by the applicable regulation. Designate and label half the sample vials the "spiked" sample set, and the other half the "unspiked" sample set. Immediately before or immediately after sampling (immediately after in the context of this procedure means after placing the sample into the sample vial, but before the sample is capped, cooled, and shipped to the laboratory for analysis), inject, either individually or as a solution, all the target compounds into each spiked sample.

2.1.2. The mass of each spiked compound shall be 40 to 60 percent of the mass expected to be present in the waste matrix. If the concentration of the target compounds in the waste are not known, the mass of each spiked compound shall be 40 to 60 percent of the limit allowed in the applicable regula-

tion. Analyze both sets of samples (spiked and unspiked) with the chosen method.

3. Calculations

For each pair of spiked and unspiked samples, determine the fraction of spiked compound recovered (R) using the following equations.

where

 $\begin{array}{ll} m_r = mass \; spiked \; compound \; measured \; (\mu \; g). \\ m_s = total \; mass \; of \; compound \; measured \; in \\ spiked \; sample \; (\mu \; g). \end{array}$

 m_u = total mass of compound measured in unspiked sample (μg).

where

S = theoretical mass of compound spiked into spiked sample (μg).

3.1. Method Evaluation

In order for the chosen method to be acceptable for a compound, 0.70≤R≤1.30 (R in this case is an average value of all the spiked and unspiked sample set R values). If the average R value does not meet this criterion for a target compound, the chosen method is not acceptable for that compound, and therefore another method shall be evaluated for acceptance (by repeating the procedures outlined above with another method).

3.2. Records and Reports

Report the average \bar{R} value in the test report and correct all reported measurements made with the method with the calculated R value for that compound by using the following equation:

Reported Result = $\frac{\text{Measured Mass of Compound}}{\text{R for that compound}}$

3.3. Optional Correction Step

If the applicable regulation allows for correction of the mass of the compound in the waste by a published $f_{\rm m}$ value, multiply the reported result calculated above with the appropriate $f_{\rm m}$ value for that compound.

[61 FR 34200, July 1, 1996, as amended at 74 FR 30230, June 25, 2009]

APPENDIX E TO PART 63—MONITORING PROCEDURE FOR NONTHOROUGHLY MIXED OPEN BIOLOGICAL TREATMENT SYSTEMS AT KRAFT PULP MILLS UNDER UNSAFE SAMPLING CONDITIONS

$I.\ Purpose$

This procedure is required to be performed in subpart S of this part, entitled National Emission Standards for Hazardous Air Pollutants from the Pulp and Paper Industry. Subpart S requires this procedure in §63.453(p)(3) to be followed during unsafe sampling conditions when it is not practicable to obtain representative samples of hazardous air pollutants (HAP) concentrations from an open biological treatment unit. It is assumed that inlet and outlet HAP concentrations from the open biological treatment unit may be obtained during the unsafe sampling conditions. The purpose of this procedure is to estimate the concentration of HAP within the open biological treatment unit based on information obtained at inlet and outlet sampling locations in units that are not thoroughly mixed and, therefore, have different concentrations of HAP at different locations within the unit.

II. Definitions

Biological treatment unit = wastewater treatment unit designed and operated to promote the growth of bacteria to destroy organic materials in wastewater.

- f_{bio} =The fraction of organic compounds in the wastewater biodegraded in a biological treatment unit.
- Fe=The fraction of applicable organic compounds emitted from the wastewater to the atmosphere.
- K1=First-order biodegradation rate constant, L/g mixed liquor volatile suspended solids (MLVSS)-hr
- KL=Liquid-phase mass transfer coefficient, m/s
- Ks=Monod biorate constant at half the maximum rate, g/m^3
- III. Test Procedure for Determination of fbio for Nonthoroughly Mixed Open Biological Treatment Units Under Unsafe Sampling Conditions

This test procedure is used under unsafe sampling conditions that do not permit practicable sampling of open biological treatment units within the unit itself, but rather relies on sampling at the inlet and outlet locations of the unit. This procedure may be used only under unsafe sampling conditions to estimate $f_{\rm bio}$. Once the unsafe conditions have passed, then the formal compliance demonstration procedures of $f_{\rm bio}$ based upon measurements within the open biological treatment unit must be completed.

A. Overview of Estimation Procedure

The steps in the estimation procedure include data collection, the estimation of concentrations within the unit, and the use of Form 1 to estimate f_{bio} . The data collection procedure consists of two separate components. The first data collection component demonstrates that the open biological treatment unit can be represented by Monod kinetics and characterizes the effectiveness of the open biological treatment unit as part of the initial performance test, and the second data collection component is used when there are unsafe sampling conditions. These two data collection components are used together in a data calculation procedure based on a Monod kinetic model to estimate the concentrations in each zone of the open biological treatment unit. After the first two components of data collection are completed, the calculation procedures are used to back estimate the zone concentrations. starting with the last zone in the series and ending with the first zone.

B. Data Collection Requirements

This method is based upon modeling the nonthoroughly mixed open biological treatment unit as a series of well-mixed zones

with internal recycling between the units and assuming that two Monod biological kinetic parameters can be used to characterize the biological removal rates in each unit. The data collection procedure consists of two separate components. The first data collection component is part of the initial performance test, and the second data collection component is used during unsafe sampling conditions.

1. Initial Performance Test

The objective of the first data collection component is to demonstrate that the open biological treatment unit can be represented by Monod kinetics and to characterize the performance of the open biological treatment unit. An appropriate value of the biorate constant, Ks, is determined using actual sampling data from the open biological treatment unit. This is done during the initial performance test when the open biological treatment unit is operating under normal conditions. This specific Ks value obtained during the initial performance test is used in the calculation procedure to characterize the open biological treatment unit during unsafe sampling conditions. The following open biological treatment unit characterization information is obtained from the first component of the data collection procedure:

- (1) The value of the biorate constant, Ks;
- (2) The number and characteristics of each zone in the open biological treatment unit (depth, area, characterization parameters for surface aeration, submerged aeration rates, biomass concentration, concentrations of organic compounds, dissolved oxygen (DO), dissolved solids, temperature, and other relevant variables); and
- (3) The recycle ratio of internal recirculation between the zones. The number of zones and the above characterization of the zones are also used to determine the performance of the unit under the unsafe sampling conditions of concern.

2. Data Collected Under Unsafe Sampling Conditions

In the second data collection component obtained under unsafe sampling conditions, the measured inlet and outlet HAP concentrations and the biomass concentration are obtained for the open biological treatment unit. After the site specific data collection is completed on the day a parameter excursion occurs, the inlet and outlet concentrations are used with the prior open biological treatment unit characterization to estimate the concentrations of HAP in each zone. The following information on the open biological treatment unit must be available in the second data collection component:

(1) Basic unit variables such as inlet and recycle wastewater flow rates, type of agitation, and operating conditions;

Environmental Protection Agency

- (2) The value of the inlet and outlet HAP concentrations; and
- (3) The biomass concentration in the open biological treatment unit.
- C. One Time Determination of a Single Value of Ks (Initial Performance Test)

A single value of Ks is calculated using Form 3 for each data set that is collected during the initial performance test. A single composite value of Ks, deemed to be representative of the biological unit, is subsequently selected so that the $f_{\rm bio}$ values calculated by the procedures in this appendix (using this single value of Ks) for the data sets collected during the initial performance test are within 10 percent of the $f_{\rm bio}$ value determined by using Form 1 with these same data sets. The value of Ks meeting these criteria is obtained by the following steps:

- (1) Determine the median of the Ks values calculated for each data set;
- (2) Estimate f_{bio} for each data set using the selected Ks value (Form 1 and Form 2);
- (3) Calculate f_{bio} for each data set using Form 1; and
- (4) Compare the $f_{\rm bio}$ values obtained in steps (2) and (3); if the $f_{\rm bio}$ value calculated using step (2) differs from that calculated using step (3) by more than 10 percent, adjust Ks (decrease Ks if the $f_{\rm bio}$ value is lower than that calculated by Form 1 and vice versa) and repeat this procedure starting at step (2). If a negative value is obtained for the values of Ks, then this negative kinetic constant may not be used with the Monod model. If a negative value of Ks is obtained, this test procedure cannot be used for evaluating the performance of the open biological treatment unit.

D. Confirmation of Monod Kinetics (Initial Performance Test)

- (1) Confirmation that the unit can be represented by Monod kinetics is made by identifying the following two items:
- (i) The zone methanol concentrations measured during the initial performance test; and
- (ii) The zone methanol concentrations estimated by the Multiple Zone Concentrations Calculations Procedure based on inlet and outlet concentrations (Column A of Form 2). For each zone, the concentration in item 1 is compared to the concentration in item 2.
- (2) For each zone, the estimated value of item 2 must be:
- (i) Within 25 percent of item 1 when item 1 exceeds 8 mg/L; or
- (ii) Within 2 mg/L of item 1 when item 1 is 8 mg/L or less.
- (3) Successful demonstration that the calculated zone concentrations meet these criteria must be achieved for 80 percent of the performance test data sets.

(4) If negative values are obtained for the values of K1 and Ks, then these negative kinetic constants may not be used with the Monod model, even if the criteria are met. If negative values are obtained, this test procedure cannot be used for evaluating the performance of the open biological treatment unit.

E. Determination of KL for Each Zone (Unsafe Sampling Conditions)

- (1) A site-specific liquid-phase mass transfer coefficient (KL) must be obtained for each zone during the unsafe sampling conditions. Do not use a default value for KL. The KL value for each zone must be based on the site-specific parameters of the specific unit. The first step in using this procedure is to calculate KL for each zone in the unit using Form 4. Form 4 outlines the procedure to follow for using mass transfer equations to determine KL. Form 4 identifies the appropriate form to use for providing the detailed calculations to support the estimate of the value of KL. Forms 5 and 6 are used to provide individual compound estimates of KL for quiescent and aerated impoundments, respectively. A computer model may be used to perform the calculations. If the WATER8 model or the most recent update to this model is used, then report the computer model input parameters that you used as an attachment to Form 4. In addition, the Bay Area Sewage Toxics Emission (BASTE) model, version 3.0, or equivalent upgrade and TOXCHEM (Environment Canada's Technology Centre Wastewater Environmega, Ltd.) model, version 1.10, or equivalent upgrade may also be used to determine KL for the open biological treatment unit with the following stipulations:
- (i) The programs must be altered to output a KL value that is based on the site-specific parameters of the unit modeled; and
- (ii) The Henry's law value listed in Form 4 must be substituted for the existing Henry's law values in the models.
- (2) The Henry's law value listed in Form 4 may be obtained from the following sources:
- (i) Values listed by EPA with temperature adjustment if needed:
- (ii) Measured values for the system of concern with temperature adjustment; or
- (iii) Literature values of Henry's law values for methanol, adjusted for temperature if needed.
- (3) Input values used in the model and corresponding output values shall become part of the documentation of the f_{bio} determination. The owner or operator should be aware that these models may not provide equivalent KL values for some types of units. To obtain an equivalent KL value in this situation, the owner or operator shall either use the appropriate procedure on Form 4 or adjust the KL value from the model to the equivalent KL value as described on Form 4.

(4) Report the input parameters that you used in the computer model on Forms 5, 6, and 7 as an attachment to Form 4. If you have submerged air flow in your unit, you must add the value of KL estimated on Form 7 to the value of KL obtained with Forms 5 and 6 before using the value of KL with Form 2.

F. Estimation of Zone Concentrations (Unsafe Sampling Conditions)

Form 2 is used to estimate the zone concentrations of HAP based on the inlet and outlet data. The value of Ks entered on the form is that single composite value of Ks discussed in section III.C of this appendix. This value of Ks is calculated during the Initial Performance Test (and subsequently updated, if necessary). A unique value of the biorate K1 is entered on line 5 of Form 2, and the inlet concentration is estimated in Column A of Form 2. The inlet concentration is located in the row of Form 2 corresponding to zone 0. If there are three zones in the system, n-3 equals 0 for the inlet concentration row. These estimated zone concentrations are then used in Form 1 to estimate f bio for the treatment unit.

G. Quality Control/Quality Assurance (QA/QC)

- A QA/QC plan outlining the procedures used to determine the measured inlet and outlet concentrations during unsafe conditions and how the zone characterization data were obtained during the initial performance test shall be prepared and submitted with the initial performance test report. The plan should include, but may not be limited to:
- (1) A description of each of the sampling methods that were used (method, procedures, time, method to avoid losses during sampling and holding, and sampling procedures) including simplified schematic drawings;
- (2) A description of how that biomass was sampled from the biotreatment unit, including methods, locations, and times;
- (3) A description of what conditions (DO, temperature, etc.) are important, what the target values are in the zones, how the factors were controlled, and how they were monitored. These conditions are primarily used to establish that the conditions of the

initial performance test correspond to the conditions of the day in question;

- (4) A description of how each analytical measurement was conducted, including preparation of solutions, dilution procedures, sampling procedures, monitoring of conditions, etc:
- (5) A description of the analytical instrumentation used, how the instruments were calibrated, and a summary of the accuracy and precision for each instrument;
- (6) A description of the test methods used to determine HAP concentrations and other measurements. Section 63.457(c)(3) specifies the test methods that must be used to determine HAP concentrations. During unsafe sampling conditions, you do not have to sample over an extended period of time or obtain more than one sample at each sample point.
- (7) A description of how data are captured, recorded, and stored; and
- (8) A description of the equations used and their solutions for sampling and analysis, including a reference to any software used for calculations and/or curve-fitting.

IV. Calculation of Individual f_{bio} (Unsafe Sampling Conditions)

Use Form 1 with your zone concentration information to estimate the value of f bio under unsafe sampling conditions. Form 1 uses measured concentrations of HAP in the unit inlet and outlet, and Form 1 also uses the estimated concentrations in each zone of the unit obtained from Form 2. This procedure may be used on an open biological treatment unit that has defined zones within the unit. Use Form 1 to determine f_{bio} for each open biological treatment unit as it exists under subpart S of part 63. The first step in using Form 1 is to calculate KL for each zone in the unit using Form 4. Form 7 must also be used if submerged aeration is used. After KL is determined using field data, obtain the concentrations of the HAP in each zone. In this alternative procedure for unsafe sampling conditions, the actual measured concentrations of the HAP in each zone are replaced with the zone concentrations that are estimated with Form 2. After KL and the zone concentrations are determined. Form 1 is used to estimate the overall unit Fe and frie for methanol.

Form 1

DATA FORM FOR THE ESTIMATION OF MULTIPLE ZONE BIODEGRADATION FROM UNIT CONCENTRATIONS

NAME OF THE FACILITY for site specific bior				
COMPOUND for site specific biorate determinat	ion			Methanol
Number of zones in the biological treatment unit	1			
VOLUME of full-scale system (cubic meters)			2	
Average DEPTH of the full-scale system (meters			3	
FLOW RATE of wastewater treated in the unit (,		4	
Recycle flow of wastewater added to the unit, if a			5	
Concentration in the wastewater treated in the un	it (mg/L)		6	
Concentration in the recycle flow, if any (mg/L)			7	
Concentration in the effluent (mg/L).		1	8	
TOTAL INLET FLOW (m3/s) line 4 plus the nu	mber on line 5		9	
TOTAL RESIDENCE TIME (s) line 2 divided by			10	
TOTAL AREA OF IMPOUNDMENT (m2) line			11	
TOTALE MEAN OF THE CONDINENT (III2) IIIC	•	1		
7 0 1 1 6 1	Estimate of KL in			
Zone Concentration for Area of the	the zone (m/s)			IR STRIPPING
number zone, Ci (mg/L) zone, A (m2)	from Form 4		K	L A Ci (g/s)
1		1 1		
2		1 1		
3		1 1		
4		1 1		
5 6		1 1		
7		1 1		
8		1 1		
9	-	1 1		
10	<u> </u>	1 1		
TOTALS sum for each zone. 12		13		
	_			
Removal by air stripping (g/s). Line 13.			14	
Loading in effluent (g/s). Line 8 times line 9.			15	
Total loading (g/s). (Line $5 * line 7$) + (line $4* line 7$)	ie 6).	l	16	
Removal by biodegradation (g/s) Line 16 minus (line 14 + line 15).	Ì	17	
Fraction biodegraded: Divide line 17 by line 16.			18	
Fraction air emissions: Divide line 14 by line 16			19	·
Fraction remaining in unit effluent: Divide line		1	20	
<u> </u>	•	L		

Form 2

DATA FORM FOR THE DETERMINATION OF ZONE CONCENTRATIONS FROM KS AND INLET/OUTLET DATA

COMPOUND for site specific biorates determination	Metha	anol
Influent Flow (m³/s)	1	
Inlet Concentration (g/m³)	2	
Outlet Concentration (g/m3) - Use value from line 3 as Ci value in column A for final Zone (zone n) in table below	3	
Saturation Coefficient, Ks (g/m3) From Form 3	4	
Biorate K1 (1/s) - Estimate	5	
Number of Zones	6	

Adjust K1 value (line 5) until Column A, Row (n - line 6) is within +/- 5% of line 2.

Instructions for completion of table: (1) Transfer value from line 3 into row n, column A. (2) Enter data for all zones into columns B, D, E, G, H, & K. (3) Beginning with row n, perform calculations for columns F_1 , J_1 , L_1 , M_1 , & O for that zone only. (4) Calculate row n-1, column A using results from previous row (i.e. J_1 , M_{i-1} , M_{i-1}), (5) Repeat steps (3) and (4) until a row of calculations has been completed for each zone. (6) row n - line 6, column A is the calculated inlet concentration.

	Α	В	С	D	E	F	G	Н
	Ci					line 5 * A*C*D		
Zone	(J _{i-1} + N _{i-1})/O _{i-1} g/m ³	Temp	(1.045)^(B-25)		Volume	*E/(line 4+ A)	KL	Area
Number	g/m ³	С		g/m ³	m ³	g/s	m/s	m ²
n								
n-1								
n-2								
n-3								
n-4								

	I	J	K	L	М	N	0
		Reaction		(1+BM _i +BM _{i+1})	BM _{i+1} * C _{i+1}	Flux	(1+BM ₊) *
Zone	A*G*H	F+I	Backmix	*C _i *line 1	*line1	L-M	line1
Number	g/s	g/s	BM _i	g/s	g/s	g/s	g/s
n							
n-1							
n-2							
n-3							
n-4							

The backmix ratio, Bmi, is the ratio of (the return flow from the zone back to the upstream zone) to (the total inlet flow into the unit). This approach assumes that the flow is sequential through the different zones.

COMPOUN	D for site spe	ecific biorates	determination			Metl	nanol	
Total Inlet F			1.0000000000000000000000000000000000000			1		
Inlet Concentration (g/m3) - Use value from line 2 as Ci-1 value in column D for Zone 1 in lable below						2		
	Α	В	С	D	E	F	G	Н
Zone	Ci	Backmix	(1+BM _i +BM _{i+1})*C _i	(1+BM _i)*C _{i-1}	BM _{i+1} * C _{i+1}	KL	Area	A*F*0
Number	g/m ³	(BM _i)	g/m ³		g/m ³	m/s	m ²	g/s
1								
2								
3								
4								
5								
,					·			
		J	K	L	M		1	0
Zone	Volume	Temp	(1.045)^(J-25)	biomass	I*K*L	M/[line 1*(D+E-C)-H]	1/A
Number	m3	С		g/m ³	gm			m ³ /g
						····		
1 2 3 4 5	Plot values ir	ı column N or	y axis, and values in- ere Ci is equal to MDL	column O on x ax or to last zone.	is, up to,	\$	3	
				Y intercept from p K1 (1/s). 1/line 3	olot. (g-s/m3)		4	
				Slope of line		MANUTA ASSOCIATION OF THE STATE	5	

Form 4

PROCEDURES FORM FOR THE	
ESTIMATION OF THE KL FROM UNIT SPECIFICATIONS	
NAME OF THE FACILITY for site specific biorate determination	
NAME OF UNIT for site specific biorate determination	
NAME OF COMPOUND	Methanol
HENRY'S LAW constant for the compound (mole fraction in gas per mole fraction in water	
at 25 degrees Celsius)	
IDENTIFY THE TYPE OF UNIT (check one box below)	
Quiescent impoundment	1
Surface agitated impoundment	2
Surface agitated impoundment with submerged air present	3
Unit with submerged aeration gas	4
1. Use Form 5 to determine KL for the surface of the quiescent impoundment. 2. Use Form 5 to determine KL for the surface of the quiescent part of the impoundment. KL for the part of the surface that is agitated, then complete Form 6 with Kq as determined ff 3. Use Form 5 to determine KL for the surface of the quiescent part of the impoundment. KL for the part of the surface that is agitated, then complete Form 6 with Kq as determined ff system KL is the sum of the KL from the completed Form 6 and the equivalent KL from Form 4. Evaluate the fraction of the surface that is agitated and the extent of the aeration. Use For the quiescent part of the surface of the impoundment. Use Form 6 to determine KL for the agitated, then complete Form 6 with Kq as determined from Form 5. The total system KL is the completed Form 6 and the equivalent KL from Form 7. See section 5.6.1 in the docume for Waste and Wastewater.	rom Form 5. Use Form 6 to determine rom Form 5. The total m 7. m 5 to determine KL for part of the surface that is the sum of the KL from nt Air Emission Models
Estimate of surface KL obtained from above procedures (m/s)	5
If the submerged aeration is present, the equivalent KL from Form 7	6
The total KL is the sum of line 5 and line 6.	7

FORM FOR CALCULATING THE MASS TRANSFER COEFFICIENT FOR A QUIESCENT SURFACE IMPOUNDMENT

FACILITY NAME for site specific biorate determination	
COMPOUND for site specific biorate determination	Methanol
00.11.00.12.10.00.00.00.00.00.00.00.00.00.00.00.00.	
Input values	
Enter the following: F - Impoundment fetch (m) D - Impoundment depth (m) U10 - Windspeed 10 m above liquid surface (m/s) Dw - Diffusivity of compound in water (cm2/s) Dether - Diffusivity of ether in water (cm2/s) µG - Viscosity of air, (g/cm-s) G - Density of air, (g/cm3) Da - Diffusivity of compound in air, (cm2/s) A - Area of impoundment, (m2) H - Henry's law constant, (atm-m3/g mol) R - Universal gas constant, (atm-m3/g mol. K) µL - Viscosity of water, (g/cm-s) L - Density of liquid, (g/cm3) T - Impoundment temperature, (C)	
Calculate the following:	
Calculate F/D:	
Calculate the liquid phase mass transfer coefficient, kL, using one of the following procedures, (m/s)	
Where F/D < 14 and U10 > 3.25 m/s, use the following procedure from MacKay and Yeun:	
Calculate the Schmidt number on the liquid side, ScL, as follows: ScL = μ L/ LDw	
Calculate the friction velocity, U*, as follows, (m/s): $U^* = 0.01 \times U10(6.1 + 0.63 \ U10)^0.5$	
Where U* is > 0.3, calculate kL as follows: kL = (1.0 x 10^-6) + (34.1 x 10^-4)U* x ScL^-0.5	
Where U* is < 0.3, calculate kL as follows: kL = $(1.0 \times 10^{-6}) + (144 \times 10^{-4})(U^*)^2.2 \times ScL^{-0.5}$	
For all other values of F/D and U10, calculate kL using the following procedure from 2Springer:	
Where U10 is < 3.25 m/s, calculate kL as follows:	
(identical to Form VII, Appendix C to Part 63)	1 of 2

Form 5

	$kL = 2.78 \times 10^{\circ}-6(Dw/Dether)^{\circ}2/3$	
	Where U10 is > 3.25 and 14 < F/D < 51.2, Calculate kL as follows: $kL = [2.605 \times 10^{4}-9(F/D) + 1.277 \times 10^{4}] \times [0.007] \times $	
	Where U10 > 3.25 m/s and F/D > 51.2, calculate kL as follows: $kL = (2.611 \times 10^{4})^{2/3}$	
B.	Calculate the gas phase mass transfer coefficient, kG, using the following procedure from MacKay and Matsasugu, (m/s):	
	Calculate the Schmidt number on the gas side, ScG, as follows: ScG = μ G/ GDa	
	Calculate the effective diameter of the impoundment, de, as follows, (m): de = (4A/3.14)^0.5	
	Calculate kG as follows, (m/s): kG = 4.82 x 10^-3 U10^.78 ScG^-0.67 de^-0.11	
C.	Calculate the partition coefficient, Keq, as follows: Keq = H/[R(T+273)]	
D.	Calculate the overall mass transfer coefficient, Kq, as follows, (m/s): $1/Kq = 1/kL + 1/(Keq-kG)$	
	Where the total impoundment surface is quiescent: KL = Kq	
	Where a portion of the impoundment surface is turbulent, continue with Form 6.	

1 of 3

Form 6

DATA FORM FOR CALCULATING THE MASS TRANSFER COEFFICIENT FOR AN AERATED SURFACE IMPOUNDMENT

	Facility Name:	
	Waste Stream Compound:	Methanol
	Enter the following:	
	J - Oxygen transfer rating of surface aerator, (lb O2/hr-hp) POWR - Total power to aerators, (hp) T - Water temperature, (C) Ot - Oxygen transfer correction factor MWL - Molecular weight of liquid At - Turbulent surface area of impoundment, (ft2) (If unknown, use values from Table 1) A - Total surface area of impoundment, (ft2) rhoL - Density of liquid, (lb/ft3) Dw - Diffusivity of constituent in water, (cm2/s) Do - Diffusivity of oxygen in water, (cm2/s) d - Impeller diameter, (cm) w - Rotational speed of impeller, (rad/s) a - Density of aerators gc - Gravitation constant, (lbm-ft/s2/lbf) d* - Impeller diameter, (ft) Da - Diffusivity of constituent in air, (cm2/s)	
	Da - Diffusivity of constituent in air, (cm2/s) MWa - Molecular weight of air R - Universal gas constant, (atm-m3/g mol. C) H = Henry's law constant, (atm-m3/g mol) Calculate the following:	
Α.	Calculate the liquid phase mass transfer coefficient, kL, using the following Equation from Thibodeaux:,	
	kL =[8.22 x 10^-9 J (POWR)(1.024)^(T-20) Ot 10^6 MWL/(At x rhoL/62.37)] (Dw/Do)^0.5, (m/s)	
B.	Calculate the gas phase mass transfer coefficient, kG, using the following procedure from Reinhardt:,	
	Calculate the viscosity of air, μ a, as follows, (g/cm.s): μ a = 4.568 x 10^-7 T + 1.7209 x 10^-4	
	Calculate the Reynold's number as follows: Re = d^2 w a/µa	
	Calculate power to impeller, PI, as follows, (ft.lbf/s): PI = 0.85 (POWR) 550/N	

(identical to Form VIII, Appendix C to Part 63)

	Calculate the power number, p, as follows:	
	$p = PI gc/(rhoL d^5 w^3)$	
	Calculate the Schmidt number, ScG, as follows:	
	ScG = μa/ (a Da)	
	Calculate the Fronde number, Fr, as follows:	
	$Fr = d^*w^2/gc$	
	Calculate kG as follows:	
	kG = 1.35 x 10^-7 Re ^1.42 p^0.4 ScG^0.5 Fr^-0.21 Da MWa/d, (m/s)	
C.	Calculate the partition coefficient, Keq, as follows:	
	Keq = H/[R(T+273)]	
D.	Calculate the overall turbulent mass transfer coefficient, Kt, as follows, (m/s):	
	1/Kt = 1/kL + 1/(Keq*kG)	
	Coloulate the guidecest mass transfer coefficient. Ve. for the increased and a second	
E.	Calculate the quiescent mass transfer coefficient, Kq, for the impoundment using Form 5.	
F.	Calculate the overall mass transfer coefficient, KL, for the impoundment as follows:	
	KL = (A-At)/A *Ka + At*Kt/A	

Form 6 Table 1

PROCEDURES FORM FOR THE ESTIMATION OF THE KL FROM WATER8 a.b

Motor			Effective	V, Agitated	aV, Area per
horsepower A	t, Turbulen	t area,	depth	volume	volume
hp	ft2	m2	ft	ft3	ft2/ft3
5	177	16.4	10	1,767	0.1002
7.5	201	18.7	10	2,010	0.1000
10	227	21	10.5	2,383	0.0953
15	284	26.4	11	3,119	0.0911
20	346	32.1	11.5	3,983	0.0869
25	415	38.6	12	4,986	0.0832
30	491	45.7	12	5,890	0.0834
40	661	61.4	13	8,587	0.0770
50	855	79.5	14	11,970	0.0714
60	1075	100	15	16,130	0.0666
75	1452	135	16	23,240	0.0625
100	2206	205	18	39.710	0.0556

a Data for a high speed (1,200) rpm) aerator with 60 cm propeller diameter (d).

b This table provides information potentially useful for the value of At.

DATA FORM FOR THE ESTIMATION OF THE EQUIVALENT KL FROM AIR STRIPPING DUE TO SUBMERGED AERATION. NAME OF THE FACILITY for site specific biorate determination COMPOUND for site specific biorate determination Methanol VENT RATE of total gas leaving the unit (G, m3/s) 1 TEMPERATURE of the liquid in the unit (deg. C) 2 ESTIMATE OF Henry's law constant (H, g/m3 in gas / g/m3 in liquid). Corrected for the temperature on line 2. 3 4 AREA OF REACTOR (m2) CALCULATION OF THE ESTIMATE OF EQUIVALENT KL [HG] ESTIMATE (m3/s) Multiply the number on line 1 by the number on line 3. Enter the results here. EQUIVALENT KL. Divide the number on line 5 by the number on line 4. 6 Enter the results on line 6.

[65 FR 80765, Dec. 22, 2000]