



Figure 1.



Figure 2.

PART 93—PROCESSED FRUITS AND VEGETABLES

Subpart A—Citrus Juices and Certain Citrus Products

- Sec.
- 93.1 General.
- 93.2 Definitions.
- 93.3 Analyses available and location of laboratory.
- 93.4 Analytical methods.
- 93.5 Fees for citrus product analyses set by cooperative agreement.

Subpart B—Peanuts, Tree Nuts, Corn and Other Oilseeds

- 93.10 General.
- 93.11 Definitions.
- 93.12 Analyses available and locations of laboratories.
- 93.13 Analytical methods.
- 93.14 Fees for aflatoxin analysis and fees for testing of other mycotoxins.
- 93.15 Fees for analytical testing of oilseeds.

AUTHORITY: 7 U.S.C. 1622, 1624.

SOURCE: 61 FR 51351, Oct. 2, 1996, unless otherwise noted.

Subpart A—Citrus Juices and Certain Citrus Products

§93.1 General.

Domestic and imported citrus products are tested to determine whether quality and grade standards are satisfied as set forth in the Florida Citrus Code.

§93.2 Definitions.

Words used in the regulations in this subpart in the singular form will import the plural, and vice versa, as the case may demand. As used throughout the regulations in this subpart, unless the context requires otherwise, the following terms will be construed to mean:

Acid. The grams of total acidity, calculated as anhydrous citric acid, per 100 grams of juice or citrus product. Total acidity is determined by titration with standard sodium hydroxide solution, using phenolphthalein as indicator.

Brix or degrees Brix. The percent by weight concentration of the total soluble solids of the juice or citrus product when tested with a Brix hydrometer calibrated at 20 °C (68 °F) and to which any applicable temperature correction has been made. The Brix or degrees Brix may be determined by any other method which gives equivalent results.

Brix value. The pure sucrose or soluble solids value of the juice or citrus product determined by using the refractometer along with the "International Scale of Refractive Indices of Sucrose Solutions" and to which the applicable correction for acidity is added. The Brix value is determined in accordance with the refractometer