

## § 761.355

## 40 CFR Ch. I (7–1–11 Edition)

the amount of time required to manually cut up larger particles of the waste to pass through a 9.5 millimeter (mm) screen.

(a) *Selecting a portion of the subsample for particle size reduction.* At the chemical extraction and analysis laboratory, pour the 19-liter subsample onto a plastic sheet or into a pan and divide the subsample into quarters. Use a random number generator or random number table to select one of these quarters.

(b) *Reduction of the particle size by the use of a 9.5 mm screen.* Collect the contents of the selected quarter of waste resulting from conducting the procedures in paragraph (a) of this section and shake the waste in a 9.5 mm screen. Separate the waste material which passes through the screen from the waste material which does not pass through the screen. Manually cut or otherwise reduce the size of all parts of the waste portion which did not pass through the 9.5 mm screen, such that each part of the waste shall pass through the 9.5 mm screen by shaking.

(c) *Drying the reduced particle size waste.* Dry all of the waste portion resulting from conducting the procedures in paragraph (b) of this section, from 10 to 15 hours in a drying oven at 100 °C. Allow the dried waste to cool to room temperature.

(d) *Mixing the dried waste.* Place all of the waste resulting from conducting the procedures in paragraph (c) of this section in a 19-liter pail or similarly sized, cylinder-shaped container. Mix the dried material according to one of the two following options:

(1) *First mixing option.* Completely close the container and roll the container a minimum of 10 complete revolutions to mix the contents.

(2) *Second mixing option.* Use a sturdy stirring rod, such as a broom handle or other device that reaches the bottom of the container, to stir the waste for a minimum of 10 complete revolutions around the container at a distance approximately half way between the outside and the center of the container.

### § 761.355 Third level of sample selection.

The third level of sample selection further reduces the size of the sub-

sample to 100 grams which is suitable for the chemical extraction and analysis procedure.

(a) Divide the subsample resulting from conducting the procedures in § 761.353 of this part into 100 gram portions.

(b) Use a random number generator or random number table to select one 100 gram size portion as a sample for a procedure used to simulate leachate generation.

(c) Dry the 100 gram sample, selected after conducting the procedure in paragraph (b) of this section, for 10 to 15 hours in a drying oven at 100 °C and cool it to the analytical laboratory room temperature before analysis using a procedure used to simulate leachate generation. This sample was dried previously in the larger quantity sample at the second level of sampling (§ 761.353(c)) and is dried a second time here (in the third level of sample selection). This dried and cooled sample must weigh at least 50 grams.

(d) If the dried and cooled sample weighs <50 grams, select additional 100 gram portions of sample one at a time by repeating the directions in paragraph (b) and (c) of this section, and add each additional 100 gram portion of sample to the first 100 gram portion until at least 50 grams of dried material is in the sample to be analyzed using a procedure used to simulate leachate generation.

### § 761.356 Conducting a leach test.

No method is specified as a procedure used to simulate leachate generation.

### § 761.357 Reporting the results of the procedure used to simulate leachate generation.

Report the results of the procedure used to simulate leachate generation as micrograms PCBs per liter of extract from a 100 gram sample of dry bulk product waste. Divide 100 grams by the grams in the sample and multiply this quotient by the number of micrograms PCBs per liter of extract to obtain the equivalent measurement from a 100 gram sample.