

container. Completely close the container, and roll it 10 or more complete revolutions to mix the contents.

(2) *Option two.* Add the 19-liter samples one at a time to a 209 liter (55 gallon) drum. Between the addition of each 19-liter sample, stir the composite using a broom handle or similar long, narrow, sturdy rod that reaches the bottom of the container. Stir the mixture for a minimum of 10 complete revolutions of the stirring instrument around the container at a distance approximately half way between the outside and center of the container.

(b) *Selecting a 19-liter subsample from the composite.* Once the composite is mixed, pour the mixture of waste out on a plastic sheet and either divide it into 19-liter size piles or make one large pile.

(1) From 19-liter sized piles, use a random number generator or random number table to select one of the piles.

(2) From one large pile, flatten the pile to a depth of 30 cm and divide it into 4 quarters of equal size. Use a random number generator or random number table to select one quarter of the pile. Further divide the selected quarter pile into 19-liter portions and use a random number generator or random number table to select one 19-liter portion. A square having a 25 cm side or a circle having a diameter of approximately 28.5 cm when projected downwards 30 cm equals approximately 19 liters.

(c) *Transferring the sample to the analytical laboratory.* Place the selected 19-liter subsample in a container, approved for shipment of the sample, to the chemical extraction and analysis laboratory, for the next step in sample selection in accordance with § 761.353.

§ 761.353 Second level of sample selection.

The second level of sample selection reduces the size of the 19-liter subsample that was collected according to either § 761.347 or § 761.348 and subsampled according to § 761.350. The purpose of the sample size reduction is to limit the amount of time required to manually cut up larger particles of the waste to pass through a 9.5 millimeter (mm) screen.

(a) *Selecting a portion of the subsample for particle size reduction.* At the chemical extraction and analysis laboratory, pour the 19-liter subsample onto a plastic sheet or into a pan and divide the subsample into quarters. Use a random number generator or random number table to select one of these quarters.

(b) *Reduction of the particle size by the use of a 9.5 mm screen.* Collect the contents of the selected quarter of waste resulting from conducting the procedures in paragraph (a) of this section and shake the waste in a 9.5 mm screen. Separate the waste material which passes through the screen from the waste material which does not pass through the screen. Manually cut or otherwise reduce the size of all parts of the waste portion which did not pass through the 9.5 mm screen, such that each part of the waste shall pass through the 9.5 mm screen by shaking.

(c) *Drying the reduced particle size waste.* Dry all of the waste portion resulting from conducting the procedures in paragraph (b) of this section, from 10 to 15 hours in a drying oven at 100 °C. Allow the dried waste to cool to room temperature.

(d) *Mixing the dried waste.* Place all of the waste resulting from conducting the procedures in paragraph (c) of this section in a 19-liter pail or similarly sized, cylinder-shaped container. Mix the dried material according to one of the two following options:

(1) *First mixing option.* Completely close the container and roll the container a minimum of 10 complete revolutions to mix the contents.

(2) *Second mixing option.* Use a sturdy stirring rod, such as a broom handle or other device that reaches the bottom of the container, to stir the waste for a minimum of 10 complete revolutions around the container at a distance approximately half way between the outside and the center of the container.

§ 761.355 Third level of sample selection.

The third level of sample selection further reduces the size of the subsample to 100 grams which is suitable for the chemical extraction and analysis procedure.

§ 761.356

(a) Divide the subsample resulting from conducting the procedures in § 761.353 of this part into 100 gram portions.

(b) Use a random number generator or random number table to select one 100 gram size portion as a sample for a procedure used to simulate leachate generation.

(c) Dry the 100 gram sample, selected after conducting the procedure in paragraph (b) of this section, for 10 to 15 hours in a drying oven at 100 °C and cool it to the analytical laboratory room temperature before analysis using a procedure used to simulate leachate generation. This sample was dried previously in the larger quantity sample at the second level of sampling (§ 761.353(c)) and is dried a second time here (in the third level of sample selection). This dried and cooled sample must weigh at least 50 grams.

(d) If the dried and cooled sample weighs <50 grams, select additional 100 gram portions of sample one at a time by repeating the directions in paragraph (b) and (c) of this section, and add each additional 100 gram portion of sample to the first 100 gram portion until at least 50 grams of dried material is in the sample to be analyzed using a procedure used to simulate leachate generation.

§ 761.356 Conducting a leach test.

No method is specified as a procedure used to simulate leachate generation.

§ 761.357 Reporting the results of the procedure used to simulate leachate generation.

Report the results of the procedure used to simulate leachate generation as micrograms PCBs per liter of extract from a 100 gram sample of dry bulk product waste. Divide 100 grams by the grams in the sample and multiply this quotient by the number of micrograms PCBs per liter of extract to obtain the equivalent measurement from a 100 gram sample.

§ 761.358 Determining the PCB concentration of samples of waste.

Use either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under

40 CFR Ch. I (7–1–14 Edition)

subpart Q of this part, for chemical extraction of PCBs from individual and composite samples of PCB bulk product waste. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

§ 761.359 Reporting the PCB concentrations in samples.

Report all sample concentrations as ppm by weight on a dry weight basis.

Subpart S—Double Wash/Rinse Method for Decontaminating Non-Porous Surfaces

SOURCE: 63 FR 35472, June 29, 1998, unless otherwise noted.

§ 761.360 Background.

The double wash/rinse procedure is used to quickly and effectively remove PCBs on surfaces. It is important to select and use the proper cleanup equipment, to conduct the procedure correctly so as not to redistribute PCBs, and to comply with disposal requirements for all cleanup materials.

§ 761.363 Applicability.

The double wash/rinse procedure includes two washing steps and two rinsing steps. The two washing and rinsing steps are slightly different depending on whether a contaminated surface was relatively clean before the spill (see § 761.372), or whether the surface was coated or covered with dust, dirt, grime, grease or another absorbent material (see § 761.375).

§ 761.366 Cleanup equipment.

(a) Use scrubbers and absorbent pads that are not dissolved by the solvents or cleaners used, and that do not shred, crumble, or leave visible fragments on the surface. Scrubbers and absorbent pads used to wash contaminated surfaces must not be reused. Scrubbers and absorbent pads for rinsing must not contain ≥ 2 ppm PCBs. Scrubbers and absorbent pads used in the second rinse of contaminated surfaces may be reused to wash contaminated surfaces.