

$$\dot{n}_{\text{exh}} = \left(x_{\text{raw/exhdry}} - x_{\text{int/exhdry}} \right) \cdot \left(1 - x_{\text{H}_2\text{Oexh}} \right) \cdot \dot{n}_{\text{dexh}} + \dot{n}_{\text{int}}$$

Eq. 1065.655-26

Example:

$$\begin{aligned} \dot{n}_{\text{int}} &= 7.930 \text{ mol/s} \\ x_{\text{raw/exhdry}} &= 0.1544 \text{ mol/mol} \\ x_{\text{int/exhdry}} &= 0.1451 \text{ mol/mol} \\ x_{\text{H}_2\text{O/exh}} &= 32.46 \text{ mmol/mol} = 0.03246 \text{ mol/mol} \\ \dot{n}_{\text{dexh}} &= 49.02 \text{ mol/s} \\ \dot{n}_{\text{exh}} &= (0.1544 - 0.1451) \cdot (1 - 0.03246) \cdot 49.02 + \\ &\quad 7.930 = 0.4411 + 7.930 = 8.371 \text{ mol/s} \end{aligned}$$

[73 FR 37331, June 30, 2008, as amended at 73 FR 59334, Oct. 8, 2008; 75 FR 23051, Apr. 30, 2010; 76 FR 57458, Sept. 15, 2011; 79 FR 23799, Apr. 28, 2014]

§ 1065.659 Removed water correction.

(a) If you remove water upstream of a concentration measurement, x , correct for the removed water. Perform this correction based on the amount of water at the concentration measurement, $x_{\text{H}_2\text{O[emission]meas}}$, and at the flow meter, $x_{\text{H}_2\text{Oexh}}$, whose flow is used to determine the mass emission rate or total mass over a test interval. For continuous analyzers downstream of a sample dryer for transient and ramped-modal cycles, you must apply this correction on a continuous basis over the test interval, even if you use one of the options in §1065.145(e)(2) that results in a constant value for $x_{\text{H}_2\text{O[emission]meas}}$ because $x_{\text{H}_2\text{Oexh}}$ varies over the test interval. For batch analyzers, determine the flow-weighted average based on the continuous $x_{\text{H}_2\text{Oexh}}$ values determined as described in paragraph (c) of this section. For batch analyzers, you may determine the flow-weighted average $x_{\text{H}_2\text{Oexh}}$ based on a single value of $x_{\text{H}_2\text{Oexh}}$ determined as described in paragraphs (c)(2) and (3) of this section, using flow-weighted average or batch concentration inputs.

(b) Determine the amount of water remaining downstream of a sample

dryer and at the concentration measurement using one of the methods described in §1065.145(e)(2). If you use a sample dryer upstream of an analyzer and if the calculated amount of water remaining downstream of the sample dryer and at the concentration measurement, $x_{\text{H}_2\text{O[emission]meas}}$, is higher than the amount of water at the flow meter, $x_{\text{H}_2\text{Oexh}}$, set $x_{\text{H}_2\text{O[emission]meas}}$ equal to $x_{\text{H}_2\text{Oexh}}$. If you use a sample dryer upstream of storage media, you must be able to demonstrate that the sample dryer is removing water continuously (*i.e.*, $x_{\text{H}_2\text{Oexh}}$ is higher than $x_{\text{H}_2\text{O[emission]meas}}$ throughout the test interval).

(c) For a concentration measurement where you did not remove water, you may set $x_{\text{H}_2\text{O[emission]meas}}$ equal to $x_{\text{H}_2\text{Oexh}}$. You may determine the amount of water at the flow meter, $x_{\text{H}_2\text{Oexh}}$, using any of the following methods:

(1) Measure the dewpoint and absolute pressure and calculate the amount of water as described in §1065.645.

(2) If the measurement comes from raw exhaust, you may determine the amount of water based on intake-air humidity, plus a chemical balance of fuel, intake air, and exhaust as described in §1065.655.

(3) If the measurement comes from diluted exhaust, you may determine the amount of water based on intake-air humidity, dilution air humidity, and a chemical balance of fuel, intake air, and exhaust as described in §1065.655.

(d) Perform a removed water correction to the concentration measurement using the following equation:

$$x = x_{[\text{emission}]_{\text{meas}}} \cdot \left(\frac{1 - x_{\text{H}_2\text{Oexh}}}{1 - x_{\text{H}_2\text{O}[\text{emission}]_{\text{meas}}}} \right)$$

Eq. 1065.659-1

Example:

$$x_{\text{COmeas}} = 29.0 \text{ } \mu\text{mol/mol}$$

$$x_{\text{H}_2\text{OCOmeas}} = 8.601 \text{ mmol/mol} = 0.008601 \text{ mol/mol}$$

$$x_{\text{H}_2\text{Oexh}} = 34.04 \text{ mmol/mol} = 0.03404 \text{ mol/mol}$$

$$x_{\text{CO}} = 29.0 \cdot \left(\frac{1 - 0.03404}{1 - 0.008601} \right)$$

$$x_{\text{CO}} = 28.3 \text{ } \mu\text{mol/mol}$$

[73 FR 37335, June 30, 2008, as amended at 76 FR 57462, Sept. 15, 2011; 79 FR 23804, Apr. 28, 2014]

§ 1065.660 THC, NMHC, and CH₄ determination.

(a) *THC determination and initial THC/CH₄ contamination corrections.* (1) If we

require you to determine THC emissions, calculate $x_{\text{THC}[\text{THC-FID}]_{\text{cor}}}$ using the initial THC contamination concentration $x_{\text{THC}[\text{THC-FID}]_{\text{init}}}$ from § 1065.520 as follows:

$$x_{\text{THC}[\text{THC-FID}]_{\text{cor}}} = x_{\text{THC}[\text{THC-FID}]_{\text{uncor}}} - x_{\text{THC}[\text{THC-FID}]_{\text{init}}}$$

Eq. 1065.660-1

Example:

$$x_{\text{THCuncor}} = 150.3 \text{ } \mu\text{mol/mol}$$

$$x_{\text{THCinit}} = 1.1 \text{ } \mu\text{mol/mol}$$

$$x_{\text{THCcor}} = 150.3 - 1.1$$

$$x_{\text{THCcor}} = 149.2 \text{ } \mu\text{mol/mol}$$

(2) For the NMHC determination described in paragraph (b) of this section, correct $x_{\text{THC}[\text{THC-FID}]}$ for initial THC contamination using Equation 1065.660-1. You may correct $x_{\text{THC}[\text{NMHC-FID}]}$ for initial contamination of the CH₄ sample train

using Equation 1065.660-1, substituting in CH₄ concentrations for THC.

(3) For the CH₄ determination described in paragraph (c) of this section, you may correct $x_{\text{THC}[\text{NMHC-FID}]}$ for initial THC contamination of the CH₄ sample train using Equation 1065.660-1, substituting in CH₄ concentrations for THC.

(b) *NMHC determination.* Use one of the following to determine NMHC concentration, x_{NMHC} :