

$$x_{\text{idriftcorrected}} = 0 + (1800.0 - 0) \cdot \frac{2 \cdot 435.5 - (0.6 + (-5.2))}{(1800.5 + 1695.8) - (0.6 + (-5.2))}$$

$$x_{\text{idriftcorrected}} = 450.2 \text{ } \mu\text{mol/mol}$$

(3) For any pre-test interval concentrations, use concentrations determined most recently before the test interval. For some test intervals, the most recent pre-zero or pre-span might have occurred before one or more previous test intervals.

(4) For any post-test interval concentrations, use concentrations determined most recently after the test interval. For some test intervals, the most recent post-zero or post-span might have occurred after one or more subsequent test intervals.

(5) If you do not record any pre-test interval analyzer response to the span gas concentration, x_{prespan} , set x_{prespan} equal to the reference concentration of the span gas:

$$x_{\text{prespan}} = x_{\text{refspan}}$$

(6) If you do not record any pre-test interval analyzer response to the zero gas concentration, x_{prezero} , set x_{prezero} equal to the reference concentration of the zero gas:

$$x_{\text{prezero}} = x_{\text{refzero}}$$

(7) Usually the reference concentration of the zero gas, x_{refzero} , is zero: $x_{\text{refzero}} = 0 \text{ } \mu\text{mol/mol}$. However, in some cases you might know that x_{refzero} has a non-zero concentration. For example, if you zero a CO_2 analyzer using ambient air, you may use the default ambient air concentration of CO_2 , which is $375 \text{ } \mu\text{mol/mol}$. In this case, $x_{\text{refzero}} = 375 \text{ } \mu\text{mol/mol}$. Note that when you zero an analyzer using a non-zero x_{refzero} , you must set the analyzer to output the actual x_{refzero} concentration. For example, if $x_{\text{refzero}} = 375 \text{ } \mu\text{mol/mol}$, set the ana-

lyzer to output a value of $375 \text{ } \mu\text{mol/mol}$ when the zero gas is flowing to the analyzer.

[70 FR 40516, July 13, 2005, as amended at 74 FR 8427, Feb. 24, 2009; 75 FR 23056, Apr. 30, 2010]

§ 1065.675 CLD quench verification calculations.

Perform CLD quench-check calculations as follows:

(a) Perform a CLD analyzer quench verification test as described in § 1065.370.

(b) Estimate the maximum expected mole fraction of water during emission testing, $x_{\text{H}_2\text{Oexp}}$. Make this estimate where the humidified NO span gas was introduced in § 1065.370(e)(6). When estimating the maximum expected mole fraction of water, consider the maximum expected water content in combustion air, fuel combustion products, and dilution air (if applicable). If you introduced the humidified NO span gas into the sample system upstream of a sample dryer during the verification test, you need not estimate the maximum expected mole fraction of water and you must set $x_{\text{H}_2\text{Oexp}}$ equal to $x_{\text{H}_2\text{Omeas}}$.

(c) Estimate the maximum expected CO_2 concentration during emission testing, $x_{\text{CO}_2\text{exp}}$. Make this estimate at the sample system location where the blended NO and CO_2 span gases are introduced according to § 1065.370(d)(10). When estimating the maximum expected CO_2 concentration, consider the maximum expected CO_2 content in fuel combustion products and dilution air.

(d) Calculate quench as follows:

$$quench = \left(\left(\frac{x_{NOwet}}{1 - x_{H_2Omeas}} - 1 \right) \cdot \frac{x_{H_2Oexp}}{x_{H_2Omeas}} + \left(\frac{x_{NOmeas}}{x_{NOact}} - 1 \right) \cdot \frac{x_{CO2exp}}{x_{CO2act}} \right) \cdot 100 \%$$

Eq. 1065.675-1

Where:

quench = amount of CLD quench.

x_{NOdry} = concentration of NO upstream of a bubbler, according to §1065.370(e)(4).

x_{NOwet} = measured concentration of NO downstream of a bubbler, according to §1065.370(e)(9).

x_{H_2Oexp} = maximum expected mole fraction of water during emission testing, according to paragraph (b) of this section.

x_{H_2Omeas} = measured mole fraction of water during the quench verification, according to §1065.370(e)(7).

x_{NOmeas} = measured concentration of NO when NO span gas is blended with CO₂ span gas, according to §1065.370(d)(10).

x_{NOact} = actual concentration of NO when NO span gas is blended with CO₂ span gas, according to §1065.370(d)(11) and calculated according to Equation 1065.675-2.

x_{CO2exp} = maximum expected concentration of CO₂ during emission testing, according to paragraph (c) of this section.

x_{CO2act} = actual concentration of CO₂ when NO span gas is blended with CO₂ span gas, according to §1065.370(d)(9).

$$x_{NOact} = \left(1 - \frac{x_{CO2act}}{x_{CO2span}} \right) \cdot x_{NOspan}$$

Eq. 1065.675-2

Where:

x_{NOspan} = the NO span gas concentration input to the gas divider, according to §1065.370(d)(5).

$x_{CO2span}$ = the CO₂ span gas concentration input to the gas divider, according to §1065.370(d)(4).

Example:

x_{NOdry} = 1800.0 µmol/mol

x_{NOwet} = 1739.6 µmol/mol

x_{H_2Oexp} = 0.030 mol/mol

x_{H_2Omeas} = 0.030 mol/mol

x_{NOmeas} = 1515.2 µmol/mol

x_{NOspan} = 3001.6 µmol/mol

x_{CO2exp} = 3.2%

$x_{CO2span}$ = 6.1%

x_{CO2act} = 2.98%

$$x_{NOact} = \left(1 - \frac{2.98}{6.1} \right) \cdot 3001.6 = 1535.24459 \text{ µmol/mol}$$

$$quench = \left(\left(\frac{1739.6}{1 - 0.030} - 1 \right) \cdot \frac{0.030}{0.030} + \left(\frac{1515.2}{1535.24459} - 1 \right) \cdot \frac{3.2}{2.98} \right) \cdot 100 \%$$

§ 1065.690

40 CFR Ch. I (7–1–14 Edition)

$quench = (-0.0036655 - 0.014020171) \cdot 100\% = -1.7685671\%$

[73 FR 59340, Oct. 8, 2008, as amended at 76 FR 57466, Sept. 15, 2011]

§ 1065.690 Buoyancy correction for PM sample media.

(a) *General.* Correct PM sample media for their buoyancy in air if you weigh them on a balance. The buoyancy correction depends on the sample media density, the density of air, and the density of the calibration weight used to calibrate the balance. The buoyancy correction does not account for the buoyancy of the PM itself, because the mass of PM typically accounts for only (0.01 to 0.10)% of the total weight. A correction to this small fraction of mass would be at the most 0.010%.

(b) *PM sample media density.* Different PM sample media have different densities. Use the known density of your sample media, or use one of the densities for some common sampling media, as follows:

(1) For PTFE-coated borosilicate glass, use a sample media density of 2300 kg/m³.

(2) For PTFE membrane (film) media with an integral support ring of

polymethylpentene that accounts for 95% of the media mass, use a sample media density of 920 kg/m³.

(3) For PTFE membrane (film) media with an integral support ring of PTFE, use a sample media density of 2144 kg/m³.

(c) *Air density.* Because a PM balance environment must be tightly controlled to an ambient temperature of (22 ±1) °C and humidity has an insignificant effect on buoyancy correction, air density is primarily a function of atmospheric pressure. Therefore you may use nominal constant values for temperature and humidity in the buoyancy correction equation in Eq. 1065.690-2.

(d) *Calibration weight density.* Use the stated density of the material of your metal calibration weight. The example calculation in this section uses a density of 8000 kg/m³, but you should know the density of your weight from the calibration weight supplier or the balance manufacturer if it is an internal weight.

(e) *Correction calculation.* Correct the PM sample media for buoyancy using the following equations:

$$m_{\text{cor}} = m_{\text{uncor}} \cdot \left(\frac{1 - \frac{\rho_{\text{air}}}{\rho_{\text{weight}}}}{1 - \frac{\rho_{\text{air}}}{\rho_{\text{media}}}} \right)$$

Eq. 1065.690-1

Where:

m_{cor} = PM mass corrected for buoyancy.

m_{uncor} = PM mass uncorrected for buoyancy.

ρ_{air} = density of air in balance environment.

ρ_{weight} = density of calibration weight used to span balance.

ρ_{media} = density of PM sample media, such as a filter.

$$\rho_{\text{air}} = \frac{p_{\text{abs}} \cdot M_{\text{mix}}}{R \cdot T_{\text{amb}}}$$

Eq. 1065.690-2