

§ 761.356

for the chemical extraction and analysis procedure.

(a) Divide the subsample resulting from conducting the procedures in § 761.353 of this part into 100 gram portions.

(b) Use a random number generator or random number table to select one 100 gram size portion as a sample for a procedure used to simulate leachate generation.

(c) Dry the 100 gram sample, selected after conducting the procedure in paragraph (b) of this section, for 10 to 15 hours in a drying oven at 100 °C and cool it to the analytical laboratory room temperature before analysis using a procedure used to simulate leachate generation. This sample was dried previously in the larger quantity sample at the second level of sampling (§ 761.353(c)) and is dried a second time here (in the third level of sample selection). This dried and cooled sample must weigh at least 50 grams.

(d) If the dried and cooled sample weighs <50 grams, select additional 100 gram portions of sample one at a time by repeating the directions in paragraph (b) and (c) of this section, and add each additional 100 gram portion of sample to the first 100 gram portion until at least 50 grams of dried material is in the sample to be analyzed using a procedure used to simulate leachate generation.

§ 761.356 Conducting a leach test.

No method is specified as a procedure used to simulate leachate generation.

§ 761.357 Reporting the results of the procedure used to simulate leachate generation.

Report the results of the procedure used to simulate leachate generation as micrograms PCBs per liter of extract from a 100 gram sample of dry bulk product waste. Divide 100 grams by the grams in the sample and multiply this quotient by the number of micrograms PCBs per liter of extract to obtain the equivalent measurement from a 100 gram sample.

§ 761.358 Determining the PCB concentration of samples of waste.

Use either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846,

40 CFR Ch. I (7–1–12 Edition)

Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part, for chemical extraction of PCBs from individual and composite samples of PCB bulk product waste. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

§ 761.359 Reporting the PCB concentrations in samples.

Report all sample concentrations as ppm by weight on a dry weight basis.

Subpart S—Double Wash/Rinse Method for Decontaminating Non-Porous Surfaces

SOURCE: 63 FR 35472, June 29, 1998, unless otherwise noted.

§ 761.360 Background.

The double wash/rinse procedure is used to quickly and effectively remove PCBs on surfaces. It is important to select and use the proper cleanup equipment, to conduct the procedure correctly so as not to redistribute PCBs, and to comply with disposal requirements for all cleanup materials.

§ 761.363 Applicability.

The double wash/rinse procedure includes two washing steps and two rinsing steps. The two washing and rinsing steps are slightly different depending on whether a contaminated surface was relatively clean before the spill (see § 761.372), or whether the surface was coated or covered with dust, dirt, grime, grease or another absorbent material (see § 761.375).

§ 761.366 Cleanup equipment.

(a) Use scrubbers and absorbent pads that are not dissolved by the solvents or cleaners used, and that do not shred, crumble, or leave visible fragments on the surface. Scrubbers and absorbent pads used to wash contaminated surfaces must not be reused. Scrubbers and absorbent pads for rinsing must not contain ≥ 2 ppm PCBs. Scrubbers and absorbent pads used in the second rinse of contaminated surfaces may be reused to wash contaminated surfaces.