

to the surface of the water in which the vessel is then floating.

(c) If the master, when recording drafts, compensates for the density of the water in which the vessel is floating, he or she shall note this density in the vessel's logbook.

§ 131.513 Verification of compliance with applicable stability requirements.

(a) After loading but before departure, and at other times necessary to assure the safety of the vessel, the master shall verify that the vessel complies with requirements in its trim-and-stability book, stability letter, Certificate of Inspection, and Loadline Certificate, whichever apply, and then enter a statement of the verification in the log book. The vessel may not leave port until it is in compliance with these requirements.

(b) When determining compliance with applicable stability requirements, the master shall ascertain the vessel's draft, trim, and stability as necessary; and any stability calculations made in support of the determination must remain aboard the vessel for the duration of the voyage.

§ 131.515 Periodic sanitary inspections.

(a) The master shall make periodic inspections of the quarters, toilet and washing spaces, serving pantries, galleys, and the like, to ensure that those spaces are maintained in a sanitary condition.

(b) The master shall enter in the vessel's logbook the results of these inspections.

§ 131.520 Hatches and other openings.

Before any vessel leaves protected waters, the master shall ensure that the vessel's exposed cargo hatches and other openings in the hull are closed; made properly watertight by the use of tarpaulins, gaskets, or similar devices; and properly secured for sea.

§ 131.525 Emergency lighting and power.

(a) The master of each vessel shall ensure that the emergency lighting and power systems are tested at least once

each week that the vessel is operated, to verify that they work.

(b) The master shall ensure that emergency generators driven by internal-combustion engines run under load for at least 2 hours at least once each month that the vessel is operated.

(c) The master shall ensure that storage batteries driving fitted systems for emergency lighting and power are tested at least once each 6 months that the vessel is operated, to demonstrate the ability of the batteries to supply the emergency loads for the period specified by Table 112.05-5(a) of this chapter for cargo vessels.

(d) The date of each test and the condition and performance of the apparatus must be noted in the vessel's logbook.

§ 131.530 Abandon-ship training and drills.

(a) Material for abandon-ship training must be aboard each vessel. The material must consist of a manual of one or more volumes, or audiovisual training aids, or both.

(1) The material must contain instructions and information about the lifesaving appliances aboard the vessel and about the best methods of survival. Any manual must be written in easily understood terms, illustrated wherever possible.

(2) If a manual is used, there must be a copy in each messroom and recreation room for crew members or in each stateroom for them. If audiovisual aids are used, they must be incorporated in the training sessions aboard under paragraph (d) of this section.

(3) The material must explain the—

- (i) Method of donning immersion suits and lifejackets carried aboard;
- (ii) Mustering at assigned stations;
- (iii) Proper boarding, launching, and clearing of survival craft and rescue boats;
- (iv) Method of launching survival craft by people within them;
- (v) Method of releasing survival craft from launching-appliances;
- (vi) Use of devices for protecting survival craft in launching-areas, where appropriate;
- (vii) Illumination of launching-areas;
- (viii) Use of each item of survival equipment;