

#### § 761.314

##### **§ 761.314 Chemical analysis of standard wipe test samples.**

Perform the chemical analysis of standard wipe test samples in accordance with § 761.272. Report sample results in micrograms per 100 cm<sup>2</sup>.

##### **§ 761.316 Interpreting PCB concentration measurements resulting from this sampling scheme.**

(a) For an individual sample taken from an approximately 1 meter square portion of the entire surface area and not composited with other samples, the status of the portion is based on the surface concentration measured in that sample. If the sample surface concentration is not equal to or lower than the cleanup level, by inference the entire 1 meter area, and not just the immediate area where the sample was taken, is not equal to or lower than the cleanup level.

(b) For areas represented by the measurement results from compositing more than one 10 centimeter by 10 centimeter sample, the measurement for the composite is the measurement for the entire area. For example, when there is a composite of 10 standard wipe test samples representing 9.5 square meters of surface area and the result of the analysis of the composite is 20 µg/100 cm<sup>2</sup>, then the entire 9.5 square meters has a PCB surface concentration of 20 µg/100 cm<sup>2</sup>, not just the area in the 10 cm by 10 cm sampled areas.

(c) For small surfaces having irregular contours, where the entire surface was sampled, measure the surface area. Divide 100 cm<sup>2</sup> by the surface area and multiply this quotient by the total number of micrograms of PCBs on the surface to obtain the equivalent measurement of micrograms per 100 cm<sup>2</sup>.

#### **Subpart Q—Self-Implementing Alternative Extraction and Chemical Analysis Procedures for Non-liquid PCB Remediation Waste Samples**

SOURCE: 63 FR 35468, June 29, 1998, unless otherwise noted.

#### 40 CFR Ch. I (7–1–14 Edition)

##### **§ 761.320 Applicability.**

This subpart describes self-implementing comparison testing requirements for chemical extraction and chemical analysis methods used as an alternative to the methods required in § 761.272 or § 761.292. Any person conducting comparison testing under this subpart must comply with the requirements of § 761.80(i), including notification. Use alternative methods only after successful completion of these comparison testing requirements and after documentation of the results of the testing.

##### **§ 761.323 Sample preparation.**

(a) The comparison study requires analysis of a minimum of 10 samples weighing at least 300 grams each. Samples of PCB remediation waste used in the comparison study must meet the following three requirements.

(1) The samples must either be taken from the PCB remediation waste at the cleanup site, or must be the same kind of material as that waste. For example, if the waste at the cleanup site is sandy soil, you must use the same kind of sandy soil in the comparison study. Do not use unrelated materials such as clay soil or dredged sediments in place of sandy soil.

(2) PCB remediation waste may contain interferences which confound or hamper sample extraction and chemical analysis. These interferences may be from chemicals or other attributes preexisting in the waste material, resulting from the PCB contamination source, or resulting from treatment to remove or destroy PCBs. Comparison study samples must also contain these interfering materials to demonstrate successful analysis in their presence. For example, a PCB remediation waste may have been co-disposed with chlorobenzene solvents or chlorinated pesticides. These chlorinated compounds would have to be present in the comparison study compounds at the same levels found, or at the highest levels expected to be found, in the PCB remediation waste. As another example, for PCB remediation waste which had been solvent washed with liquid amines to