

must be protected inside and outside from corrosion.

(d) Each CO₂ system must have a pressure relief valve set to relieve between 168 and 196 kilograms per square centimeter (2,400 and 2,800 pounds per square inch) in the distribution manifold or other location that protects the piping when all branch line shut off valves are closed.

(e) The end of each branch line in a CO₂ system must extend at least 50 millimeters (2 inches) beyond the last discharge outlet and be closed with a cap or plug.

(f) Piping, valves, and fittings in a CO₂ system must be securely supported and protected from damage.

(g) Each CO₂ system must have drains and dirt traps located where dirt or moisture can accumulate in the system.

(h) Discharge piping in a CO₂ system may not be used for any other purpose except as part of a fire detection system.

(i) Piping in a CO₂ system that passes through accommodation spaces must not have drains or other openings within these spaces.

§ 108.449 Piping tests.

(a) Each test prescribed in (b), (c), and (d) of this section must be performed upon completion of the piping installation.

(b) When tested with CO₂ or other inert gas under a pressure of 70 kilograms per square centimeter (1000 pounds per square inch), with no additional gas introduced into the system, the leakage in the piping from the cylinders to the stop valves in the manifold must not allow a pressure drop of more than 10.5 kilograms per square centimeter (150 pounds per square inch) per minute for a 2 minute period.

(c) When tested with CO₂ or other inert gas under a pressure of 42 kilograms per square centimeter (600 pounds per square inch), with no additional gas introduced into the system, the leakage in each branch line must not allow a pressure drop of more than 10.5 kilograms per square centimeter (150 pounds per square inch) per minute for a 2-minute period. The distribution piping must be capped within the protected space.

(d) Small independent systems protecting emergency generator rooms, lamp lockers and similar small spaces need not meet the tests prescribed in paragraphs (a) and (b) of this section if they are tested by blowing out the piping with air at a pressure of at least 7 kilograms per square centimeter (100 pounds per square inch).

§ 108.451 CO₂ storage.

(a) Except as provided in paragraph (b) of this section, each cylinder of a CO₂ system must be outside each space protected by the system and in a location that would be accessible if a fire occurred in any space protected by the system.

(b) A CO₂ system that has a CO₂ supply of 136 kilograms (300 pounds) or less may have one or more cylinders in the space protected by the system if the space has a heat detection system to activate the system automatically in addition to the remote and manual controls required by this subpart.

(c) Each space that contains cylinders of a CO₂ system must be ventilated and designed to prevent an ambient temperature of more than 54 °C. (130 °F.)

(d) Each cylinder in a CO₂ system must be securely fastened, supported, protected from damage, in an accessible location, and capable of removal from that location.

(e) Each unit must have a means for weighing cylinders of a CO₂ system.

(f) A cylinder in a CO₂ system may not be mounted in a position that is inclined more than 30° from a vertical position, except that a cylinder having flexible or bent siphon tubes may be mounted in a position that is inclined up to 80° from the vertical. The bottom of each cylinder when mounted must be at least 5 centimeters (2 inches) from the deck.

(g) If a cylinder does not have a check valve on its independent cylinder discharge, it must have a plug or cap to close the outlet when the cylinder is moved.

[CGD 73-251, 43 FR 56808, Dec. 4, 1978, as amended by CGD 84-044, 53 FR 7749, Mar. 10, 1988]